TABLE OF CONTENTS - Continued

CHIME

*CHIME INOPERATIVE AT ALL TIMES 94
*CHIME INOPERATIVE WITH DRIVER SEAT BELT UNFASTENED. 95
*CHIME INOPERATIVE WITH EXTERIOR LAMPS ON AND DRIVER DOOR OPEN .96
*CHIME INOPERATIVE WITH KEY IN IGNITION, DRIVER'S DOOR OPEN 97
*CHIME SOUNDS WITH DRIVER SEAT BELT FASTENED 100
*CHIME SOUNDS WITH DRIVER'S DOOR OPEN, KEY REMOVED 102

COMMUNICATION

*NO RESPONSE FROM AIRBAG CONTROL MODULE 103
*NO RESPONSE FROM CONTROLLER ANTILOCK BRAKE 105
*NO RESPONSE FROM INSTRUMENT CLUSTER 107
*NO RESPONSE FROM PCM (PCI BUS) - NGC 109
*NO RESPONSE FROM PCM (PCM SCI ONLY) - NGC 110
*NO RESPONSE FROM RADIO 113
*NO RESPONSE FROM SENTRY KEY IMMOBILIZER MODULE. 115
*NO RESPONSE FROM TRANSMISSION CONTROL MODULE - NGC 117
*PCI BUS COMMUNICATION FAILURE 120

COMPASS/MINI-TRIP COMPUTER

*COMPASS/TEMP MODULE WILL NOT CALIBRATE 123
*COMPASS/TEMPERATURE MODULE INOPERATIVE. 124
*TEMPERATURE DISPLAY INACCURATE OR INOPERATIVE. 125

ELECTRICALLY HEATED SYSTEMS

*REAR WINDOW DEFOGGER INOPERATIVE. 127
*REAR WINDOW DEFOGGER SWITCH INDICATOR LAMP INOPERATIVE. 130

INSTRUMENT CLUSTER

ACM MESSAGE NOT REC'D BY MIC. 131
AIR BAG LAMP CIRCUIT OPEN 132
AIR BAG LAMP CIRCUIT SHORT 133
CHECKSUM FAILURE 134
PANEL DIMMER OPEN 135
PCM MESSAGE NOT REC'D BY MIC. 137
SKIM MESSAGE NOT REC'D BY MIC 138
*"NO BUS" IN VF DISPLAY 139
*"NO FUSE" IN VF DISPLAY 140
*4WD INDICATOR INOPERATIVE 141
*ABS INDICATOR INOPERATIVE 144
*AIR BAG INDICATOR INOPERATIVE 145
*ALL GAUGES INOPERATIVE. 146
*ANY PCI BUS INDICATOR INOPERATIVE 148
*AXLE LOCK INDICATOR PROBLEMS. 149
*BRAKE WARNING INDICATOR ALWAYS ON 152
*BRAKE WARNING INDICATOR INOPERATIVE 153
*FOG LAMP INDICATOR INOPERATIVE - DOMESTIC 155
*HIGH BEAM INDICATOR INOPERATIVE. 156
*ONE GAUGE INOPERATIVE 157
*PANEL DIMMNG INOPERATIVE 158
*REAR FOG LAMP INDICATOR INOPERATIVE - BUX ONLY. 159
*SEAT BELT INDICATOR NOT OPERATING PROPERLY 160
*SPEEDOMETER INACCURATE OR INOPERATIVE. 162