PASSENGER OFF INDICATOR CIRCUIT SHORT TO GROUND — Continued

TEST	ACTION	APPLICABILITY
3	Is this vehicle equipped with a Passenger Airbag On - Off Switch? Yes → Go To 4 No → With the DRBIII® in MISCELLANEOUS, read the Configure for Airbag ON - OFF Switch current status. Enter the number 1 and press enter to re configure the ACM for NO AIRBAG ON/OFF SWITCH. Perform __AIRBAG VERIFICATION TEST - VER 1.	All
4	Gain access to the Passenger Airbag On - Off Switch connector. Is the Passenger Airbag On - Off Switch connected to the dash harness? Yes → Go To 5 No → Connect the Passenger Airbag On - Off switch to the dash harness connector. Perform __AIRBAG VERIFICATION TEST - VER 1.	All
5	**WARNING: TO AVOID PERSONAL INJURY OR DEATH, TURN IGNITION OFF, DISCONNECT THE BATTERY AND WAIT TWO MINUTES BEFORE PROCEEDING.** Disconnect the Passenger On - Off Switch connector. **NOTE: Check connectors - Clean and repair as necessary.** **WARNING: TO AVOID PERSONAL INJURY OR DEATH, TURN IGNITION ON, THEN RECONNECT THE BATTERY.** Measure the voltage on the Fused Ignition Switch Output Run - Start circuit between the PAB On - Off Switch connector and ground. Is the voltage above 10.0 volts? Yes → Go To 6 No → Repair the open Fused ignition Switch Output Run - Start circuit. Perform __AIRBAG VERIFICATION TEST - VER 1.	All
6	**WARNING: TURN THE IGNITION OFF, DISCONNECT THE BATTERY AND WAIT TWO MINUTES BEFORE PROCEEDING.** Disconnect the Passenger Airbag On - Off Switch. **NOTE: Check connectors - Clean and repair as necessary.** Measure the resistance between PAB On - Off Switch terminals 3 and 4. Is the resistance approximately 14 ohms? Yes → Go To 7 No → Replace the Passenger Airbag ON - OFF Switch in accordance with the service information. Perform __AIRBAG VERIFICATION TEST - VER 1.	All