Symptom:

***CHIME SOUNDS WITH DRIVER SEAT BELT FASTENED**

POSSIBLE CAUSES
SEAT BELT SWITCH STATUS WRONG
SEAT BELT SWITCH OPEN
GROUND WIRE OPEN
SEAT BELT SWITCH SENSE OPEN
INSTRUMENT CLUSTER - SEAT BELT SENSE OPEN

TEST	ACTION	APPLICABILITY
1	Ensure the drivers seat belt is fastened. With the DRB III select: Electro Mech Cluster Input/Outputs. Turn the ignition on. Read the Driver Belt SW status. Does the DRB III show Driver Belt SW: CLOSED? Yes → Replace the Instrument Cluster. Perform BODY VERIFICATION TEST - VER 1. No → Go To 2	All
2	Disconnect the Seat Belt Switch connector. Turn all interior lights off. Measure the resistance of the Ground circuit in the Seat Belt Switch connector to ground. Is the resistance below 5.0 ohms? Yes → Go To 3 No → Repair the open Ground wire. Perform BODY VERIFICATION TEST - VER 1.	All
3	Disconnect the Seat Belt Switch connector. Connect a jumper wire between Seat Belt Switch Sense circuit and the Ground circuit in the Seat Belt Switch connector. With the DRB III select: Electro Mech Cluster Input/Outputs. Turn the ignition on. Read the Driver Belt SW status. Does the DRB III show Driver Belt SW: CLOSED? Yes → Repair Seat Belt switch pigtail wiring or replace Buckle assembly. Perform BODY VERIFICATION TEST - VER 1. No → Go To 4	All
4	Turn the ignition off. Remove the Instrument Cluster from the instrument panel. Disconnect the Seat Belt Switch connector. Measure the resistance of the Seat Belt Switch Sense circuit between the Instrument Cluster C2 connector and the Seat Belt Switch connector. Is the resistance below 5.0 ohms? Yes → Go To 5 No → Repair the open Seat Belt Switch Sense wire. Perform BODY VERIFICATION TEST - VER 1.	All