Symptom:
*4WD INDICATOR INOPERATIVE

POSSIBLE CAUSES
INTERMITTENT CONDITION
TRANSFER CASE SWITCH - EXCEPT OFF-ROAD PACKAGE
4WD INDICATOR CIRCUIT OPEN
TRANSFER CASE SWITCH GROUND CIRCUIT OPEN - EXCEPT OFF-ROAD PACKAGE
TRANSFER CASE SWITCH - OFF-ROAD PACKAGE
TRANSFER CASE POSITION SENSOR INPUT CIRCUIT OPEN
TRANSFER CASE SWITCH GROUND CIRCUIT OPEN - OFF-ROAD PACKAGE
INSTRUMENT CLUSTER - EXCEPT OFF-ROAD PACKAGE
INSTRUMENT CLUSTER - OFF-ROAD PACKAGE

TEST	ACTION	APPLICABILITY
1	Is vehicle equipped with the optional Off-Road Package? Yes → Go To 2 No → Go To 6	All
2	Perform the Instrument Cluster self-test. Turn the ignition off. Press and hold the Trip Reset button. Turn the ignition on. Observe the 4WD indicator during the self-test. **NOTE: The Instrument Cluster self-test can be initiated using the DRBIII®.** Did the 4WD indicator illuminate during the self-test? Yes → Go To 3 No → Replace and configure the Instrument Cluster in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1.	All
3	Turn the ignition on, Transfer Case Shift Lever in 2H. With the DRBIII® in Inputs/Outputs, read the 4WD Switch state. Place the Transfer Case Shift Lever in 4H or 4L while observing the 4WD Switch State. Did the Does the DRBIII® display 4H or 4L? Yes → The condition is not present at this time. Monitor DRBIII® parameters while wiggling the related wire harness. Refer to any Technical Service Bulletins (TSB) that may apply. Visually inspect the related wiring harness and connector terminals. Perform BODY VERIFICATION TEST - VER 1. No → Go To 4	All