*4WD INDICATOR INOPERATIVE — Continued

TEST	ACTION	APPLICABILITY
4	Turn the ignition off. Disconnect the Transfer Case Switch harness connector. Connect a jumper wire between cavity 1 and cavity 2. Turn the ignition on. With the DRBIII®, read the 4WD Switch input. Does the DRBIII® display ″Closed?″ Yes → Replace the Transfer Case Switch in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1. No → Go To 5	All
5	Turn the ignition off. Disconnect the Transfer Case Switch harness connector. Disconnect the PCM C1 harness connector. Measure the resistance of the Transfer Case Position Sensor Input circuit between the T/Case Switch connector and the PCM C1 connector. Is the resistance above 5.0 ohms? Yes → Repair the Transfer Case Position Sensor Input circuit for an open. Perform BODY VERIFICATION TEST - VER 1. No → Repair the Transfer Case Switch Ground circuit for an open. Perform BODY VERIFICATION TEST - VER 1.	All
6	Turn the ignition on. With the DRBIII®, select Body, MIC, then Inputs/Outputs. Move the transfer case shift lever from the 2H to the 4H or 4L position. Does the DRBIII® display 4WD Switch ″Closed″ with the shift lever in the 4H or 4L position? Yes → Replace and configure the Instrument Cluster in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1. No → Go To 7	All
7	Turn the ignition off. Disconnect the Transfer Case Switch harness connector. Connect a jumper wire between cavity A and cavity B. Turn the ignition on. With the DRBIII®, read the 4WD Switch input. Does the DRBIII® display ″Closed″. Yes → Replace the Transfer Case Switch in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1. No → Go To 8	All