Symptom:
*AIR BAG INDICATOR INOPERATIVE

POSSIBLE CAUSES
INSTRUMENT CLUSTER
AIR BAG INDICATOR DTC

TEST	ACTION	APPLICABILITY
1	**NOTE: The Instrument Cluster Air Bag Indicator will not illuminate during the cluster Self Test. The indicator is controlled by PCI Bus messages received from the Air Bag Control Module (ACM).** **NOTE: The ACM will command the indicator on when the ignition is cycled to the Run/Start position.** With the DRBIII®, select Body, then MIC, read DTCs. Does the DRBIII® display Air Bag Lamp Open or Air Bag Lamp Shorted? Yes → Refer to the Service Information and perform the appropriate symptom. Perform BODY VERIFICATION TEST - VER 1. No → Replace the Instrument Cluster in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1.	All