Symptom:
*AXLE LOCK INDICATOR PROBLEMS

POSSIBLE CAUSES
DTC PRESENT
AXLE LOCKER SWITCH FUSED B(+) CIRCUIT OPEN
AXLE LOCKER SWITCH GROUND CIRCUIT OPEN
FRONT LOCKER REQUEST CIRCUIT OPEN
REAR LOCKER REQUEST CIRCUIT OPEN
AXLE LOCK SWITCH
INTERMITTENT CONDITION
INSTRUMENT CLUSTER

TEST	ACTION	APPLICABILITY
1	**NOTE: The following tests are to diagnose an inoperative Axle Lock indicator. If the Axle Lock indicator flashes, the Enable conditions have not been met to lock the axle, or an axle mechanical fault exists.** **NOTE: The Front Axle Lock and Rear Axle Lock indicators can NOT be diagnosed using the Instrument Cluster self test.** With the DRBIII®, read DTCs. Are any ABS, PCM, VSS, or Transfer Case DTCs present? Yes → Refer to DRIVEABILITY or TRANSMISSION/TRANSFER CASE information for the related symptom(s). Perform BODY VERIFICATION TEST - VER 1. No → Go To 2	All
2	Select the inoperative indicator. Rear Axle Lock Indicator Go To 3 Front Axle Lock Indicator Go To 8	All
3	Perform the Axle Locker test. Turn the ignition on. Place transfer case in 4WD Lo and visually confirm by observing the 4WD indicator. Drive the vehicle at less than 10 MPH (16 km/h). Press the Axle Lock switch once. Did the Rear Axle Lock indicator illuminate? Yes → The condition is not present at this time. Monitor DRBIII® parameters while wiggling the related wire harness. Refer to any Technical Service Bulletins(TSB) that may apply. Visually inspect the related wiring harness and connector terminals. Perform BODY VERIFICATION TEST - VER 1. No → Go To 4	All