Symptom:
*BRAKE WARNING INDICATOR ALWAYS ON

POSSIBLE CAUSES
BRAKE WARNING INDICATOR CIRCUIT SHORT TO GROUND
BRAKE WARNING INDICATOR SWITCH
PARK BRAKE SWITCH

TEST	ACTION	APPLICABILITY
1	**NOTE: Ensure that the Base brake system functions properly and that the Brake Master Cylinder is filled with proper amount of fluid.** **NOTE: If equipped, diagnose and repair any ABS DTCs before continuing with this test.** Turn the ignition off. Disconnect the Park Brake Switch harness connector. Turn the ignition on and observe the Brake Warning Indicator. Does the Brake Warning Indicator remain illuminated? Yes → Go To 2 No → Replace the Park Brake Switch in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1.	All
2	Turn the ignition off. Disconnect the Brake Warning Indicator Switch harness connector. Connect a jumper wire between cavity 1 and cavity 2. Turn the ignition on and observe the Brake Warning Indicator. Does the Brake Warning Indicator remain illuminated? Yes → Repair the Brake Warning Indicator circuit for a short to ground. Perform BODY VERIFICATION TEST - VER 1. No → Replace the Brake Warning Indicator Switch in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1.	All