Symptom:

***VF DISPLAY INOPERATIVE**

POSSIBLE CAUSES
INSTRUMENT CLUSTER

TEST	ACTION	APPLICABILITY
1	**NOTE: Ensure that all other Instrument Cluster functions operate properly.** Turn the ignition off. Perform the Instrument Cluster Self Test. Did any or all of the VF display fail to operate? Repair Replace and configure the Instrument Cluster in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1.	All