Symptom:

*VF ODOMETER INOPERATIVE WITH DOOR OPEN

POSSIBLE CAUSES
DEFECTIVE FUSE
DOOR AJAR SENSE CIRCUIT SHORT TO VOLTAGE
AJAR SWITCH
DOOR AJAR SWITCH SENSE CIRCUIT OPEN
DOOR AJAR SWITCH GROUND CIRCUIT OPEN
INSTRUMENT CLUSTER

TEST	ACTION	APPLICABILITY
1	Turn the ignition off. Inspect the #4 fuse in the Fuse Block. If the fuse is open, replace with proper rated fuse. **NOTE: Ensure that the ignition is in the off position.** Open the door(s). Inspect the #4 fuse in the Fuse Block. Is the fuse open? Yes → Go To 2 No → Go To 3	All
2	Turn the ignition off. Disconnect the Instrument Cluster C2 harness connector. Check connectors - Clean/repair as necessary. Measure the voltage between the Door Ajar Switch Sense circuit and ground. **NOTE: This test will work for either the Driver or Passenger Door Ajar Switch Sense circuit.** Is there any voltage present? Yes → Repair the Door Ajar Switch Sense circuit for a short to voltage. Perform BODY VERIFICATION TEST - VER 1. No → Go To 3	All
3	Turn the ignition off. Disconnect the Door Ajar Switch harness connector. **NOTE: This test will work for the Driver or Passenger Door Ajar Switch.** Connect a jumper wire between cavity 1 and cavity 3. Does the VF Odometer illuminate? Yes → Replace the inoperative Door Ajar Switch in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1. No → Go To 4	All