# TABLE OF CONTENTS


**1.0 INTRODUCTION . . . . . 1**

**1.1** SYSTEM COVERAGE . . . . . 1
**1.2** SIX-STEP TROUBLESHOOTING PROCEDURE . . . . . 1

**2.0 IDENTIFICATION OF SYSTEM . . . . . 1**

**3.0 SYSTEM DESCRIPTION AND FUNCTIONAL OPERATION . . . . . 1**

**3.1** TEVES MARK 20I SYSTEM DESCRIPTION . . . . . 1
**3.1.1** PEDAL FEEL/VEHICLE CHARACTERISTICS . . . . . 2
**3.1.2** SYSTEM COMPONENTS . . . . . 2
**3.1.3** ABS AND BRAKE WARNING INDICATORS . . . . . 2
**3.1.4** CONTROLLER ANTILOCK BRAKE (CAB) . . . . . 2
**3.1.5** HYDRAULIC CONTROL UNIT . . . . . 3
**3.1.6** RELAYS/SWITCHES . . . . . 3
**3.1.7** SENSORS . . . . . 3
**3.2** DIAGNOSTIC TROUBLE CODES . . . . . 4
**3.2.1** SYSTEM INITIALIZATION . . . . . 4
**3.2.2** DIAGNOSTIC MODE . . . . . 4
**3.2.3** INTERMITTENT DIAGNOSTIC TROUBLE CODES . . . . . 4
**3.3** AXLE LOCK . . . . . 4
**3.3.1** GENERAL . . . . . 4
**3.3.2** DESCRIPTION . . . . . 4
**3.4** USING THE DRBIII® . . . . . 5
**3.5** DRBIII® ERROR MESSAGES . . . . . 5
**3.5.1** DRBIII® DOES NOT POWER UP (BLANK SCREEN) . . . . . 5
**3.5.2** DISPLAY IS NOT VISIBLE . . . . . 5

**4.0 DISCLAIMERS, SAFETY WARNINGS . . . . . 5**

**4.1** DISCLAIMERS . . . . . 5
**4.2** SAFETY . . . . . 6
**4.2.1** TECHNICIAN SAFETY INFORMATION . . . . . 6
**4.2.2** VEHICLE PREPARATION FOR TESTING . . . . . 6
**4.2.3** SERVICING SUB-ASSEMBLIES . . . . . 6
**4.2.4** DRBIII® SAFETY INFORMATION . . . . . 6
**4.3** WARNING . . . . . 6
**4.3.1** VEHICLE DAMAGE WARNINGS . . . . . 6
**4.3.2** ROAD TESTING A COMPLAINT VEHICLE . . . . . 7
**4.4** DIAGNOSIS . . . . . 7

**5.0 REQUIRED TOOLS AND EQUIPMENT . . . . . 7**

**6.0 GLOSSARY OF TERMS . . . . . 8**

**7.0 DIAGNOSTIC INFORMATION AND PROCEDURES . . . . . 9**

**BRAKES (CAB)**
CAB POWER FEED CIRCUIT . . . . . 10
CONTROLLER FAILURE . . . . . 13
G-SWITCH NOT PROCESSABLE . . . . . 15
LEFT FRONT SENSOR CIRCUIT FAILURE . . . . . 19
LEFT REAR SENSOR CIRCUIT FAILURE . . . . . 19