Symptom:

G-SWITCH NOT PROCESSABLE

When Monitored and Set Condition:

G-SWITCH NOT PROCESSABLE

When Monitored: Ignition on. The CAB sends a test signal out to the G-switch and monitors the sense circuits #1 and #2.

Set Condition: If the sense circuits are open for 2 minutes while driving or an otherwise improper signal is detected at any time, the Diagnostic Trouble Code (DTC) is set.

POSSIBLE CAUSES
G-SWITCH TEST SIGNAL CIRCUIT OPEN
INTERMITTENT DTC
G-SWITCH TEST SIGNAL OR SENSE CIRCUIT SHORT TO VOLTAGE OR GROUND
G-SWITCH SIGNAL CIRCUIT INTERNAL OPEN
CAB - TEST SIGNAL CIRCUIT OPEN
G-SWITCH #1 SENSE CIRCUIT OPEN
G-SWITCH #1 SENSE SWITCH OPEN
CAB - #1 SENSE CIRCUIT OPEN
G-SWITCH #2 SENSE CIRCUIT OPEN
G-SWITCH #2 SENSE SWITCH OPEN
CAB - #2 SENSE CIRCUIT OPEN

TEST	ACTION	APPLICABILITY
1	Turn the ignition on. With the DRBIII®, read the status of the G-Switch internal switches. What is the status of both of the G-Switches? Both G-Switches are closed. Go To 2 Both G-Switches are open. Go To 3 Only the #1 G-Switch is open. Go To 7 Only the #2 G-Switch is open. Go To 10	All