## G-SWITCH NOT PROCESSABLE — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 2 | Turn the ignition off.<br>Visually inspect the related wiring harness. Look for any chafed, pierced, pinched, or partially broken wires.<br>Visually inspect the related wire harness connectors. Look for broken, bent, pushed out, or corroded terminals.<br>Refer to any Hotline letters or Technical Service Bulletins that may apply.<br>Were any problems found?<br>Yes → Repair as necessary.<br>Perform ABS VERIFICATION TEST - VER 1.<br>No → Test Complete. | All |
| 3 | Turn the ignition off.<br>Disconnect the CAB connector.<br>**Check connector - Clean/repair as necessary.**<br>Disconnect the G-Switch Sensor Connector.<br>**NOTE: Check connector - Clean/repair as necessary.**<br>Measure the resistance of the G-Switch Test Signal circuit.<br>Is the resistance below 5 ohms?<br>Yes → Go To 4<br>No → Repair the G-Switch Test Signal Circuit Open.<br>Perform ABS VERIFICATION TEST - VER 1. | All |
| 4 | Turn the ignition off.<br>Disconnect the CAB Connector.<br>**Check connector - Clean/repair as necessary.**<br>Disconnect the G-Switch Sensor Connector.<br>**Check connector - Clean/repair as necessary.**<br>Turn the ignition on.<br>Using a 12-volt test light connected to ground, check the Test Signal and both Sense circuits.<br>Using a 12-volt test light connected to 12-volts, check the Test Signal and both Sense circuits.<br>**CAUTION: The test light should not light at any test point.**<br>Does the test light illuminate at any test point?<br>Yes → Repair the G-Switch Test Signal or Sense circuit for a short to voltage or ground.<br>Perform ABS VERIFICATION TEST - VER 1.<br>No → Go To 5 | All |
| 5 | Turn the ignition off.<br>Disconnect the G-Switch Connector.<br>**Check connector - Clean/repair as necessary.**<br>Remove G-Switch from vehicle.<br>While holding the G-Switch level, measure the resistance of the G-Switch Test Signal circuit and the G-Switch #1 Sense circuit in the G-Switch connector.<br>Is the resistance below 5 ohms?<br>Yes → Go To 6<br>No → Replace G-Switch.<br>Perform ABS VERIFICATION TEST - VER 1. | All |