G-SWITCH NOT PROCESSABLE — Continued

TEST	ACTION	APPLICABILITY
6	If there are no potential causes remaining, view repair. Repair Replace the CAB. Perform ABS VERIFICATION TEST - VER 1.	All
7	Turn the ignition off. Disconnect the CAB Connector. **Note: Check connector - Clean/repair as necessary.** Disconnect the G-Switch Sensor Connector. Measure the resistance of the G-Switch #1 Sense Circuit. Is the resistance below 5 ohms? Yes → Go To 8 No → Repair the G-Switch #1 Sense circuit open. Perform ABS VERIFICATION TEST - VER 1.	All
8	Turn the ignition off. **Check connector - Clean/repair as necessary.** Remove G-Switch from vehicle. While holding the G-Switch level, measure the resistance of the G-Switch Test Signal circuit and the G-Switch #1 Sense circuit in the G-Switch connector. Is the resistance below 5 ohms? Yes → Go To 9 No → Replace G-Switch Assembly. Perform ABS VERIFICATION TEST - VER 1.	All
9	If there are no potential causes remaining, view repair. Repair Replace the CAB. Perform ABS VERIFICATION TEST - VER 1.	All
10	Turn the ignition off. Disconnect the CAB Connector. **Note: Check connector - Clean/repair as necessary.** Disconnect the G-Switch Connector. **Note: Check connector - Clean/repair as necessary.** Measure the resistance of the G-Switch #2 Sense Circuit. Is the resistance below 5 ohms? Yes → Go To 11 No → Repair the G-Switch #2 Sense Circuit Open. Perform ABS VERIFICATION TEST - VER 1.	All
11	Turn the ignition off. Disconnect the G-Switch connector. **Note: Check connector - Clean/repair as necessary.** Remove the G-Switch from vehicle. While holding the G-Switch level, measure the resistance of the G-Switch Test Signal circuit and the G-Switch #2 Sense circuit in the G-Switch connector. Is the resistance below 5 ohms? Yes → Go To 12 No → Replace the G-Switch Assembly. Perform ABS VERIFICATION TEST - VER 1.	All