## LEFT FRONT SENSOR CIRCUIT FAILURE — Continued

| POSSIBLE CAUSES |
|---|
| WHEEL SPEED SENSOR (+) OR (-) CIRCUIT SHORTED TO GROUND |
| WHEEL SPEED SENSOR CIRCUITS SHORTED TOGETHER |
| SPEED SENSOR (+) OR (-) CIRCUIT OPEN |
| CAB - INTERNAL SHORT OR OPEN |

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | Turn the ignition on.<br>With the DRBIII®, read DTC's.<br>With the DRBIII®, erase DTC's.<br>Turn the ignition off.<br>Turn the ignition on.<br>With the DRBIII®, read DTC's.<br>Does the DRBIII® display a Wheel Speed Sensor Circuit Failure DTC?<br><br>Yes → Go To 2<br><br>No → Go To 9 | All |
| 2 | Turn the ignition off.<br>Inspect the affected Wheel Speed Sensor and Connector.<br>Is the Sensor or Connector Damaged?<br><br>Yes → Repair as necessary.<br>Perform ABS VERIFICATION TEST - VER 1.<br><br>No → Go To 3 | All |
| 3 | Turn the ignition off.<br>Disconnect the affected Wheel Speed Sensor connector.<br>**Note: Check connector - Clean/repair as necessary.**<br>Measure the resistance across the Wheel Speed Sensor (+) and (-) circuits at the Sensor side of the connector.<br>Measure the resistance between ground and the (+) and (-) circuits on the Sensor side of the connector.<br>Is the Sensor resistance 900 to 1300 ohms and resistance to ground more than 15k ohms?<br><br>Yes → Go To 4<br><br>No → Repair the short or replace the Wheel Speed Sensor, as necessary.<br>Perform ABS VERIFICATION TEST - VER 1. | All |
| 4 | Turn the ignition off.<br>Disconnect the affected Wheel Speed Sensor connector.<br>**Note: Check connector - Clean/repair as necessary.**<br>Disconnect the CAB connector.<br>**Note: Check connector - Clean/repair as necessary.**<br>Turn the ignition on.<br>Measure the voltage of the Wheel Speed Sensor (+) and (-) circuits.<br>Is the voltage above 1 volt at either circuit?<br><br>Yes → Repair the Wheel Speed Sensor circuit for a short to voltage.<br>Perform ABS VERIFICATION TEST - VER 1.<br><br>No → Go To 5 | All |