Symptom:
*REAR AXLE LOCK INOPERATIVE

POSSIBLE CAUSES
CHECKING OPERATION
INSTRUMENT CLUSTER NOT PROPERLY CONFIGURED
VSS, PCM, OR TRANSFER CASE DTC'S PRESENT
OPEN FUSE IN PDC
AXLE LOCK SWITCH GROUND CIRCUIT OPEN
FUSED B(+) CIRCUIT OPEN TO AXLE LOCK SWITCH
AXLE LOCK SWITCH FAILURE

TEST	ACTION	APPLICABILITY
1	Turn the ignition on. Ensure Transfer Case is in 4 ″LOW″ range. Vehicle speed is less than 16 km/h (10 mph). Depress the Axle Lock Switch once. Does the Axle Lock Switch indicator illuminate? Yes → The condition is not present at this time. Monitor DRBIII® parameters while wiggling the related wiring harness. Refer to any Technical Service Bulletins(TSB) that may apply. Visually inspect the related wiring harness and connector terminals. Perform BODY VERIFICATION TEST - VER 1. No → Go To 2	All
2	Turn the ignition on. With the DRBIII®, ensure the Instrument Cluster is correctly configured for Tire size, Axle type, and Transfer Case. Is the vehicle Instrument Cluster configured correctly? Yes → Go To 3 No → Refer to Body for the related symptom(s). Perform BODY VERIFICATION TEST - VER 1.	All
3	Turn the ignition on. With the DRBIII®, ensure there are no VSS, PCM, or Transfer Case DTC's present. **NOTE: When ALL conditions are met the Instrument Cluster Enable 1 State must indicate - LOW.** Vehicle must indicate the transfer case is in 4 ″LOW″ range, the ignition ON, and vehicle speed is less than 16 km/h (10 mph). Are any VSS, PCM, or Transfer Case DTC's present? Yes → Refer to the appropriate service information for the related DTC's. Perform BODY VERIFICATION TEST - VER 1. No → Go To 4	All