Symptom:

CAB POWER FEED CIRCUIT

When Monitored and Set Condition:

CAB POWER FEED CIRCUIT

When Monitored: Ignition on. The CAB monitors the Fused B(+) circuit at all times for proper system voltage.

Set Condition: If the Fused B(+) voltage is missing when the CAB detects that an internal main driver is not ″on″, the Diagnostic Trouble Code (DTC) is set.

POSSIBLE CAUSES
INTERMITTENT DTC
B(+) CIRCUIT SHORTED TO GROUND
BLOWN FUSE - FUSED B(+) CIRCUIT
CAB - FUSED B(+) CIRCUIT SHORTED TO GROUND
FUSED B(+) CIRCUIT OPEN
NO B+ SUPPLY TO FUSE
CAB - FUSED B(+) CIRCUIT OPEN

TEST	ACTION	APPLICABILITY
1	Turn the ignition on. With the DRBIII®, erase DTC's. Turn the ignition off. Turn the ignition on. Drive the vehicle above 25 km/h (15 mph) for at least 10 seconds. Stop the vehicle. With the DRBIII®, read DTC's. Does the DRBIII® display CAB Power Feed Circuit DTC present right now? Yes → Go To 2 No → Go To 9	All
2	Turn the ignition off. Remove and Inspect Fuse 12 in the PDC. Is the Fuse blown? Yes → Go To 3 No → Go To 6	All