CAB POWER FEED CIRCUIT — Continued

TEST	ACTION	APPLICABILITY
3	Turn the ignition off. Remove Fuse 12 from the PDC. Disconnect the CAB harness connector. **Note: Check connector - Clean/repair as necessary.** Using a test light connected to 12 volts, probe the Fused B(+) Circuit. Does the test light illuminate brightly? Yes → Repair the Fused B(+) Circuit Shorted to Ground. Perform ABS VERIFICATION TEST - VER 1. No → Go To 4	All
4	Turn the ignition off. Remove Fuse 12 from the PDC. The CAB must be connected for the results of this test to be valid. Using a test light connected to 12 volts, probe the Fused B+ circuit at the PDC fuse terminal. Does the test light illuminate brightly? Yes → Replace the Controller Antilock Brake in accordance with the Service Information. Perform ABS VERIFICATION TEST - VER 1. No → Go To 5	All
5	Turn the ignition off. If there are no potential causes remaining, view repair. Continue Replace the Fuse. Perform ABS VERIFICATION TEST - VER 1.	All
6	Turn the ignition off. Remove Fuse 12 from the PDC. Disconnect the CAB harness connector. **Note: Check connector - Clean/repair as necessary.** Measure the resistance of the Fused B+ circuit between the PDC fuse terminal and the CAB connector. Is the resistance below 5 ohms? Yes → Go To 7 No → Repair the Fused B+ circuit for an open. Perform ABS VERIFICATION TEST - VER 1.	All
7	Remove Fuse 12 from the PDC. Turn the ignition on. Measure the voltage of the Fused B+ supply to Fuse 12 in the PDC. Is the voltage above 10 volts? Yes → Go To 8 No → Repair the B+ Supply circuit for an open. Perform ABS VERIFICATION TEST - VER 1.	All
8	If there are no potential causes remaining, view repair. Repair Replace the Controller Antilock Brake in accordance with the Service Information. Perform ABS VERIFICATION TEST - VER 1.	All