LEFT FRONT SENSOR SIGNAL FAILURE — Continued

TEST	ACTION	APPLICABILITY
5	Turn the ignition off. Inspect the wheel bearing for excessive runout or clearance. **Note: Refer to the appropriate service information, if necessary, for procedures or specifications.** Is the bearing runout OK ? Yes → Go To 6 No → Repair as necessary. The CAB must sense all four wheels at 25 km/h (15 mph) before it will extinguish the ABS Indicator. Perform ABS VERIFICATION TEST - VER 1.	All
6	Turn the ignition off. Raise the affected wheel off the ground. Disconnect the Wheel Speed Sensor connector at the affected wheel. Set up an AC voltmeter to read the output of the Wheel Speed Sensor. Quickly rotate the wheel by spinning the tire by hand. Measure the Wheel Speed Sensor AC voltage output. Does the voltage go above 650 millivolts as the wheel is rotated? Yes → Replace the Controller Antilock Brake in accordance with the Service Information. Perform ABS VERIFICATION TEST - VER 1. No → Replace the Wheel Speed Sensor in accordance with the Service Information. The CAB must sense all four wheels at 25 km/h (15 mph) before it will extinguish the ABS Indicator. Perform ABS VERIFICATION TEST - VER 1.	All
7	Turn the ignition off. Visually inspect the affected Wheel Speed Sensor for correct installation. Visually inspect the Tone Wheel for looseness and correct installation. Visually inspect the wiring harness for loose or intermittent connections. Visually inspect mechanical brake components. Inspect for conditions that may cause lockup or drag. Inspect for seized caliper or wheel cylinder piston. Inspect all components for a condition which may cause a Wheel Speed Signal DTC to set. Is any Component Damaged? Yes → Repair as necessary. The CAB must sense all four wheels at 25 km/h (15 mph) before it will extinguish the ABS Indicator. Perform ABS VERIFICATION TEST - VER 1. No → Test Complete.	All