Symptom:

***FRONT AXLE LOCK INDICATOR REMAINS FLASHING**

POSSIBLE CAUSES
CHECKING OPERATION
INTERMITTENT CONDITION
FUSED B(+) CIRCUIT OPEN TO THE FRONT LOCKER RELAY
FRONT LOCKER RELAY
FRONT LOCKER RELAY OUTPUT CIRCUIT OPEN
FRONT LOCKER PUMP GROUND CIRCUIT OPEN
FRONT LOCKER PUMP
FRONT LOCKER INDICATOR SWITCH SENSE CIRCUIT OPEN
FRONT LOCKER INDCATOR SWITCH GROUND CIRCUIT OPEN
MECHANICAL FAULT EXISTS

TEST	ACTION	APPLICABILITY
1	**NOTE: For this test to be valid the Rear Axle must be locked and the Rear Lock indicator must be illuminated.** Turn the ignition on. Ensure Transfer Case is in 4 ″LOW″ range. Vehicle speed is less than 16km/h (10 mph). Depress the Axle Lock Switch once. Does the Front Axle Lock indicator remain flashing? Yes → Go To 2 No → The condition is not present at this time. Monitor DRBIII® parameters while wiggling the related wiring harness. Refer to any Technical Service Bulletins(TSB) that may apply. Visually inspect the related wiring harness and connector terminals. Perform BODY VERIFICATION TEST - VER 1.	All
2	Disconnect the Front Locker Relay. Measure the voltage of the Fused B(+) circuit in the Front Locker Relay PDC connector. Is the voltage above 10 volts? Yes → Go To 3 No → Repair the Fused B(+) circuit for an open. Perform BODY VERIFICATION TEST - VER 1.	All
3	Turn the ignition off. Replace the Front Locker Relay with a known good part. Turn the ignition on. Ensure Transfer Case is in 4 ″LOW″ range. Depress the Axle Lock Switch once. Did the Front Locker Pump turn ON? Yes → Replace the Front Locker Relay. Perform BODY VERIFICATION TEST - VER 1. No → Go To 4	All