*REAR AXLE LOCK INOPERATIVE — Continued

TEST	ACTION	APPLICABILITY
4	Inspect Fuse 26 in the PDC. Is the Fuse open, missing, or loose? Yes → Replace the open or missing fuse. If the fuse is open make sure to check for a short to ground in the Fused B(+) circuit from the fuse to the switch. Perform BODY VERIFICATION TEST - VER 1. No → Go To 5	All
5	Turn on the Park lamps. Observe the Axle Lock Switch. Does the Axle Lock Switch illuminate? Yes → Go To 6 No → Repair the Axle Lock Switch Ground circuit for an open. Perform BODY VERIFICATION TEST - VER 1.	All
6	Disconnect the Axle Lock Switch connector. Measure the voltage of the Fused B(+) circuit in the Axle Lock Switch connector. Is the voltage above 10 volts? Yes → Replace the Axle Lock Switch in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1. No → Repair the Fused B(+) circuit for an open. Perform BODY VERIFICATION TEST - VER 1.	All