

---

# HEBCPF

## Holomorphic-Embedding-Based Continuation Power-Flow All-Solutions Solver

---

*Finding all real-valued solutions of the AC power-flow equations  
via the ellipsoidal formulation, holomorphic embedding, Padé approximation, and  
numerical continuation*

**Release: MATLAB v3.202606**

Pure-MATLAB build (no compiled binaries; cross-platform) — validated,  
robustness-hardened

**Method:** Holomorphic Embedding Based Continuation (HEBC)

**Originating work:** D. Wu and B. Wang, *IEEE Access*, 2019

**Foundations:** Elliptical branch tracing — B. Lesieutre & D. Wu,  
Allerton 2015;  
Algebraic set preserving mappings — D. Wu,  
Ph.D. dissertation, UW–Madison, 2017

**Document:** User Guide and Reference Manual

When you publish results obtained with this solver, please cite the HEBC paper (see Section 13).

July 4, 2026

# Contents

|           |                                                                                     |           |
|-----------|-------------------------------------------------------------------------------------|-----------|
| <b>1</b>  | <b>Overview</b>                                                                     | <b>2</b>  |
| <b>2</b>  | <b>Requirements and dependencies</b>                                                | <b>2</b>  |
| <b>3</b>  | <b>Installation</b>                                                                 | <b>3</b>  |
| <b>4</b>  | <b>Quick start</b>                                                                  | <b>3</b>  |
| <b>5</b>  | <b>User options</b>                                                                 | <b>4</b>  |
| 5.1       | Where the settings live: <code>solver_params.m</code> . . . . .                     | 4         |
| 5.2       | Choosing which cases to run . . . . .                                               | 4         |
| 5.3       | Load scaling . . . . .                                                              | 4         |
| 5.4       | Choosing a framework: serial, <code>parfor</code> , <code>parfeval</code> . . . . . | 4         |
| 5.5       | Padé pole estimation (consensus) . . . . .                                          | 5         |
| 5.6       | Programmatic single-case runs: <code>run_merged_case</code> . . . . .               | 5         |
| <b>6</b>  | <b>How the solver works</b>                                                         | <b>6</b>  |
| 6.1       | Elliptical formulation . . . . .                                                    | 6         |
| 6.2       | Holomorphic embedding and Padé . . . . .                                            | 6         |
| 6.3       | Hybrid switching and warm start . . . . .                                           | 6         |
| 6.4       | Continuation details . . . . .                                                      | 6         |
| 6.5       | Validated, robustness-hardened configuration . . . . .                              | 7         |
| <b>7</b>  | <b>Parameter reference</b>                                                          | <b>7</b>  |
| 7.1       | Continuation / step control . . . . .                                               | 7         |
| 7.2       | Holomorphic / hand-off control . . . . .                                            | 8         |
| 7.3       | Consensus pole estimation . . . . .                                                 | 8         |
| 7.4       | Fold-proximity and stall control . . . . .                                          | 8         |
| 7.5       | Holomorphic degree . . . . .                                                        | 9         |
| <b>8</b>  | <b>Outputs</b>                                                                      | <b>9</b>  |
| <b>9</b>  | <b>File map</b>                                                                     | <b>9</b>  |
| <b>10</b> | <b>Portability and performance</b>                                                  | <b>10</b> |
| <b>11</b> | <b>Troubleshooting</b>                                                              | <b>10</b> |
| <b>12</b> | <b>License and third-party notices</b>                                              | <b>10</b> |
| <b>13</b> | <b>Citing this solver</b>                                                           | <b>11</b> |

## 1 Overview

HEBCPF computes **all** real-valued solutions of the AC power-flow (load-flow) equations for a given network, rather than the single operating point returned by a conventional solver. Knowing the complete solution set is essential for transient-stability energy-function methods (locating type-1 unstable equilibria), voltage-stability analysis, and the study of multiple high-voltage operating points.

The solver implements the **Holomorphic Embedding Based Continuation (HEBC)** method of Wu and Wang (see Section 13). The power-flow equations are first recast in an *elliptical form* (Lesieutre and Wu, 2015) so that every solution-tracing curve is a bounded loop; the loops are then followed by a hybrid numerical scheme:

- **Holomorphic embedding** traverses the smooth (non-singular) portions of a curve in a few very large steps, using power-series / Padé evaluation of the holomorphically-embedded voltages;
- a classical **predictor–corrector continuation** takes over only in the neighbourhood of singular points (turning points / folds), where it steps carefully through the fold and hands control back to the holomorphic routine.

Each time the tracing (homotopy) parameter crosses zero, a power-flow solution has been found. Starting from one known operating point (from MATPOWER’s `runpf`), the solver recursively traces the curves emanating from every discovered solution until no new solution appears.

This release adds a **consensus Padé-pole estimator** to the classic method (Section 5.5), which stabilises the placement of the holomorphic/continuation hand-off by agreeing a singularity estimate across several buses rather than trusting a single bus.

Three execution frameworks share the identical numerical hot path:

| Framework           | Entry script                      | Best for                                |
|---------------------|-----------------------------------|-----------------------------------------|
| Serial              | <code>run_batch.m</code>          | small cases, debugging, reproducibility |
| Parallel (parfor)   | <code>run_batch_par.m</code>      | medium cases, one worker per equation   |
| Parallel (parfeval) | <code>run_batch_parfeval.m</code> | <b>large cases (recommended)</b>        |

## 2 Requirements and dependencies

### MATLAB (required).

MATLAB R2022a or later, on *any* platform — this is a pure-MATLAB build with no compiled binaries. Uses `sparse`, `linsolve`, `lu`, and standard linear algebra.

### MATPOWER (required).

MATPOWER must be installed and on the MATLAB path. The setup stage calls MATPOWER functions including `runpf` for the initial operating point, `makeYbus` for the bus-admittance matrix, and `idx_bus/idx_brch` for MATPOWER matrix indices. The solver reads the bundled MATPOWER-format `caseXXX.m` data files, but does *not* ship `runpf`, `makeYbus`, `idx_bus`, `idx_brch`, or their dependencies — those come from MATPOWER (<https://matpower.org>).

### Parallel Computing Toolbox (optional).

Required *only* for the two parallel frameworks (`run_batch_par.m`, `run_batch_parfeval.m`). The serial framework runs without it.

### No compiler needed.

This is the pure-MATLAB build: it runs on any MATLAB platform with no MEX / codegen step. For roughly  $2\times$  faster serial tracing on Windows x64, use the companion compiled build (HEBCPF\_MEX\_v3.202606); the numerical results are identical.

## 3 Installation

1. Install MATLAB and MATPOWER; confirm `runpf` works (which `runpf` returns a path).
2. Unpack this folder (HEBCPF\_matlab\_v3.202606) anywhere on disk.
3. Add the folder to the MATLAB path each session:

```
>> cd '<path>\HEBCPF_matlab_v3.202606'
>> addpath(pwd)
```

4. Add only this one HEBCPF release folder to the MATLAB path. Do not add all four release folders simultaneously, because they contain many functions and cases with the same names.
5. Nothing else is needed — this build is pure MATLAB, so there are no binaries to install or compile, on any platform.

## 4 Quick start

Before running any driver, confirm MATLAB can find MATPOWER:

```
>> which runpf
>> which makeYbus
```

Both commands should return paths inside the MATPOWER installation.

From a system shell (non-interactive `-batch`):

```
:: SERIAL
matlab -sd "<path>\HEBCPF_matlab_v3.202606" -batch "addpath(pwd); run('run_batch.m
    ')"

:: PARALLEL (parfor)
matlab -sd "<path>\HEBCPF_matlab_v3.202606" -batch "addpath(pwd); run('
    run_batch_par.m')"
```

```
:: PARALLEL (parfeval, recommended for big cases)
matlab -sd "<path>\HEBCPF_matlab_v3.202606" -batch "addpath(pwd); run('
    run_batch_parfeval.m')"
```

From an interactive MATLAB session:

```
>> addpath(pwd)
>> run_batch           % serial batch
>> run_batch_par       % parallel (parfor)
>> run_batch_parfeval  % parallel (parfeval)
>> r = run_merged_case('case14mod','parfeval'); % one case, any mode
>> r.solutions, r.max_residual, r.wall_time
```

The two parallel drivers start a local `parpool` automatically (default worker count) if none is running. The one-time pool start-up is excluded from the reported timing.

## 5 User options

### 5.1 Where the settings live: `solver_params.m`

Every tunable constant is defined in one place — the function `solver_params.m`, which returns a `param` struct consumed by the whole solver (`hybrid_traceloops` → holomorphic step, continuation, corrector). To change any behaviour, edit the relevant line in `solver_params.m`; all three frameworks *and* the parallel workers read the same file, so one edit applies everywhere. Every field is documented inline, and Section 7 tables the ones you are most likely to touch. (The only tunable kept outside this file is the Padé `degree`, set in the run drivers and `main.m`.)

### 5.2 Choosing which cases to run

Each driver has a list near the top:

```
cases_to_run = { 'case9', 'case14mod', 'case39', ... };
```

Comment out or add case names. Bundled test systems (expected solution counts, collapsing antipodal pairs, in parentheses):

|                |                          |                 |                |
|----------------|--------------------------|-----------------|----------------|
| case3 (6)      | case4gs (6)              | case4BB0 (14)   | case4BBc (12)  |
| case5loop (10) | case5Salam (10)          | case6ww (6)     | case7Salam (4) |
| case9 (8)      | case9Q (8)               | case14mod (30)  | case33bw (16)  |
| case39 (176)   | case30/case_ieee30 (472) | case57mod (606) | case57 (1322)  |

### 5.3 Load scaling

Each driver contains

```
factor = 1 + 0.19*(0); % default = 1 (nominal load)
```

Changing the multiplier (the “(0)”) scales all bus loads and generator outputs, letting you sweep load level. Leave it at 1 to reproduce the nominal solution counts.

### 5.4 Choosing a framework: `serial`, `parfor`, `parfeval`

All three frameworks compute the *identical* solution set; they differ only in how the per-equation curve traces are distributed across processes.

#### Serial (`run_batch.m`)

one process traces every curve in turn. Needs no toolbox; fully deterministic and the easiest to debug.

#### `parfor` (`run_batch_par.m`)

MATLAB’s parallel *for*-loop. The equations of one starting solution are grouped into a *batch* and dealt out to the worker pool, but the loop then **blocks until the whole batch has finished** before it proceeds. It is simple and effective, yet a batch runs only as fast as its *slowest* equation: if one curve is long or stalls, the other workers sit idle at that synchronisation barrier until it completes.

#### `parfeval` (`run_batch_parfeval.m`)

*asynchronous* task submission. Each equation is submitted individually via `parfeval`, and results are collected in the order they *complete*, whatever that order is. A sliding window keeps

the pool saturated: the instant a worker finishes a curve it is handed the next one, *without* waiting for the others. This removes the per-batch barrier and keeps every worker busy, so it is the fastest framework on large systems with uneven curve lengths (e.g. `case30`, `case57mod`). The only trade-off is that the *order* in which curves are traced is non-deterministic (it depends on which worker finishes first); the final solution set is identical, but which curve happens to discover a given solution can differ between runs.

In one line: `parfor` is *synchronous, batch-at-a-time* and blocks on the slowest curve; `parfeval` is *asynchronous, task-at-a-time* with no idle waiting — prefer it for large cases. Both start a local pool automatically and require the Parallel Computing Toolbox; the one-time pool start-up is excluded from the reported timing.

## 5.5 Padé pole estimation (consensus)

The hand-off from the holomorphic routine to the continuation routine is driven by an estimate of the nearest singularity, taken from the real roots (poles) of the Padé denominator. This build estimates that pole by **consensus** across a fixed set of buses (`param.pole_buses`, default `2:6`, auto-filtered to  $\leq$  bus count): the true singularity sits at nearly the same magnitude on every bus, whereas spurious (Froissart) poles are bus-specific. The estimator takes the smallest pole magnitude agreed on by at least half of the sampled buses (clustered within `param.pole_cl_tol`), and falls back to the global smallest if no consensus forms. This replaces the legacy single-/random-bus pole pick and is one of the robustness improvements in this build (Section 6.5). To change it, edit `param.pole_buses`, `param.pole_consensus`, or `param.pole_cl_tol` in `solver_params.m`.

## 5.6 Programmatic single-case runs: `run_merged_case`

While the `run_batch*` drivers loop over a list of cases and write CSV summaries, `run_merged_case` is the **unified single-case harness**: it runs *one* case in *any* of the three frameworks behind a single function call and returns a structured, machine-readable result instead of printing to the console.

```
[result, solutions] = run_merged_case(case_name, mode, close_pool_on_finish)
%   mode = 'serial' | 'parfor' | 'parfeval'
```

It performs the identical preprocessing as the batch drivers (it reuses `main.m` as the setup template, substituting the requested case for the active `mpc=case...` line), traces the case in the selected framework, and **self-verifies** by recomputing the maximum residual  $|z^T M_i z - b_i|$  over every solution  $z$  and every equation  $i$ . The call never throws: on failure it returns a **FAIL** result rather than erroring. The returned `result` struct contains:

| Field                          | Meaning                                                               |
|--------------------------------|-----------------------------------------------------------------------|
| <code>status</code>            | 'PASS' or 'FAIL'                                                      |
| <code>case_name, mode</code>   | echoed inputs                                                         |
| <code>buses</code>             | number of buses                                                       |
| <code>solutions</code>         | number of solutions found                                             |
| <code>max_residual</code>      | largest constraint residual over the solution set (correctness check) |
| <code>wall_time</code>         | trace wall-clock time (excludes pool start-up)                        |
| <code>error_id, message</code> | populated only on FAIL                                                |

The second output, `solutions`, is the full solution matrix `Zsave` (each column a solution). Typical uses: A/B comparison of the three frameworks on one case (identical setup, compare

`wall_time/solutions/max_residual`); automated regression or validation checks; and obtaining the solution set and residual directly as return values. Because it reads `main.m`, that file must remain in the folder for this harness to work.

## 6 How the solver works

### 6.1 Elliptical formulation

In rectangular voltage coordinates  $x = [V_d^\top V_q^\top]^\top$ , each power-flow equation is a quadratic  $x^\top C_i x = b_i$ . These native surfaces are unbounded (hyperbolic), so raw branch tracing can run off to infinity. Following Lesieutre–Wu (2015) and Wu’s thesis, a positive-definite *base ellipsoid* is added to every equation, producing an equivalent system

$$x^\top M_i x = 1, \quad M_i = M_i^\top \succ 0, \quad i = 1, \dots, 2N_{\text{bus}},$$

whose zero set is *identical* to the original (algebraic-set preserving) but whose every equation is now a high-dimensional ellipse centred at the origin. Relaxing one equation with a tracing parameter  $\alpha$  (the code variable `aal`) yields a 1-dimensional curve; because the ellipses are compact, each connected component of that curve is a **bounded loop** (generically diffeomorphic to a circle), so a trace must return to its start. Solutions occur wherever  $\alpha = 0$  along the loop.

### 6.2 Holomorphic embedding and Padé

Rather than crawl the loop with small predictor–corrector steps, HEBC embeds the tracing parameter into the complex plane and represents each bus voltage as a holomorphic function, computed as a power series (to degree `degree.act`, default 15). All series degrees share a single LU factorisation, so the coefficients are cheap. A **Padé approximant** (balanced numerator/-denominator degree, for maximal convergence radius) then extrapolates the voltages far along the curve in one step, until the power mismatch exceeds `param.mismatch_error`. The real roots of the Padé denominator reveal the location of the nearest singularity on the curve.

### 6.3 Hybrid switching and warm start

When a holomorphic step approaches a singularity — signalled either by the corrector failing to converge, or by the holomorphic increment  $|\Delta\alpha|$  collapsing — the solver switches to predictor–corrector continuation to pass through the fold. To avoid a slow “cold” warm-up, a **warm starter** sets the first continuation step to a fraction of the estimated distance to the singularity (and no larger than a fraction of the last holomorphic step), then builds a quadratic predictor. After the fold is cleared, control returns to the holomorphic routine. One holomorphic step costs about  $4\times$  a continuation step but typically covers  $\approx 8\text{--}9$  continuation steps of arc, which is where the speed-up comes from.

### 6.4 Continuation details

The continuation phase uses a pseudo-arclength predictor (quadratic, from the last three points), a Newton corrector (*Phase I*), and a variable-rescaling corrector (*Phase II*) for badly-conditioned near-singular arcs whose secant slope exceeds `param.slope_max`. The step length adapts to the corrector iteration count toward a target of `param.targetsteps`. Each  $\alpha$  sign change triggers a solution extraction and a duplicate check; a trace terminates when it returns to its starting point (within `closure` tolerance) or exhausts the alternation cap `param.outnum`.

## 6.5 Validated, robustness-hardened configuration

This v3 build ships a *validated* default configuration that hardens the tracer against the numerical failures (wrong-branch drift and non-closing loops near sharp folds) that can occur with the legacy settings. Four changes matter most, all in `solver_params.m`:

- **Consensus pole estimate** (`pole_buses = 2:6`, `pole_consensus`) — rejects spurious per-bus poles that would place the hand-off badly (Section 5.5);
- **Turning-point slope limit** `slope_max = 1e4` — keeps the continuation active through steep near-singular arcs instead of handing back too early (values of  $5 \times 10^4$  and above re-break the hard case118 curves);
- **Hand-back hysteresis** `handback = 0.5` — travels far enough past a turning point before returning to the holomorphic step that the curve cannot be misled onto an adjacent wrong branch;
- **Fold-proximity step caps** `init_cap_k = 1500` (caps the first continuation step after a hand-back) and `max_adapt = true` (an adaptive per-step cap driven by the secant-slope change) — both prevent a large step from jumping a sharp apex onto the wrong branch.

These defaults are exact on every verifiable case (`case3 ... case57mod`). Unless you are experimenting, leave them as shipped; the tables in Section 7 describe each.

## 7 Parameter reference

All tunables live in `solver_params.m` — a single function returning the `param` struct that every framework and every parallel worker reads. Edit a line there and the change applies everywhere. The file is fully commented; the tables below cover the parameters you are most likely to adjust, with this build’s shipped defaults.

### 7.1 Continuation / step control

| Parameter                | Default                    | Meaning                                                             |
|--------------------------|----------------------------|---------------------------------------------------------------------|
| <code>sstep</code>       | <code>1e-5</code>          | Base arc-length step scale for the continuation.                    |
| <code>targetsteps</code> | <code>3</code>             | Target number of corrector iterations; drives step-size adaptation. |
| <code>imax</code>        | <code>40</code>            | Maximum Newton iterations per corrector step.                       |
| <code>smax</code>        | <code>20000</code>         | Maximum continuation steps per <code>branch_trace</code> call.      |
| <code>maximumstep</code> | <code>8000</code>          | Maximum step-size multiplier (Phase I ceiling base).                |
| <code>maxphase1</code>   | <code>maximumstep/2</code> | Maximum step in Phase I.                                            |
| <code>maxphase2</code>   | <code>maxphase1/10</code>  | Maximum step in Phase II.                                           |
| <code>minimumstep</code> | <code>1e-2</code>          | Minimum step-size multiplier.                                       |
| <code>ef</code>          | <code>1e-8</code>          | Corrector residual tolerance $\ F\ $ .                              |
| <code>ex</code>          | <code>1e-7</code>          | Corrector step tolerance $\ \Delta x\ $ .                           |
| <code>PS</code>          | <code>300</code>           | Phase II (rescaling) duration, in steps.                            |
| <code>maxsolu</code>     | <code>100</code>           | Maximum solutions collected per traced loop.                        |
| <code>maxskip</code>     | <code>50</code>            | Consecutive numerical stalls tolerated before the loop is skipped.  |
| <code>dev</code>         | <code>20</code>            | Console print interval (display only).                              |



## 7.2 Holomorphic / hand-off control

| Parameter      | Default | Meaning                                                                                                                                                                                      |
|----------------|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| mismatch_error | 1e-4    | Maximum holomorphic power-mismatch accepted before shrinking the arc.                                                                                                                        |
| holonum        | 50      | Maximum Padé steps per outer iteration before forcing continuation.                                                                                                                          |
| holo_arc_max   | 0.01    | Maximum holomorphic arc length per step.                                                                                                                                                     |
| outnum         | 500     | Cap on holomorphic↔continuation alternations per curve (a stall burns this cap).                                                                                                             |
| slope_max      | 1e4     | Maximum secant slope at which a turning point is accepted as passed. <b>1e4</b> is the validated value; $\geq 5 \times 10^4$ re-breaks the hard case118 curves.                              |
| aal_min        | 1e-6    | Minimum homotopy-parameter increment; the unit for <b>handback</b> .                                                                                                                         |
| im_tol         | 1e-3    | Imaginary-part tolerance for accepting a Padé root as a real pole.                                                                                                                           |
| handback       | 0.5     | Hand-back hysteresis ( $\times$ aal_min): how far past a turning point to travel before returning to the holomorphic routine. 0.5 is validated across all cases (the legacy build used 0.1). |
| interval       | 1       | Stride for the turning-point finite-difference test.                                                                                                                                         |

## 7.3 Consensus pole estimation

| Parameter      | Default | Meaning                                                                                              |
|----------------|---------|------------------------------------------------------------------------------------------------------|
| pole_buses     | 2:6     | Buses sampled for the consensus pole estimate (auto-filtered to $\leq$ bus count).                   |
| pole_consensus | true    | If true, take the smallest pole agreed on by $\geq$ half the sampled buses; else the global minimum. |
| pole_cl_tol    | 0.10    | Relative magnitude tolerance for clustering “the same pole” across buses.                            |

## 7.4 Fold-proximity and stall control

These are the robustness controls added in v3 (Section 6.5).

| Parameter      | Default | Meaning                                                                                                                                                                                                          |
|----------------|---------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| init_cap_k     | 1500    | Caps the first continuation step after a hand-back at $\text{init\_cap\_k} \times \text{holo\_arc} / \text{sstep}$ , so a fold entry cannot be overshoot (Inf disables).                                         |
| max_adapt      | true    | Adaptive per-step ceiling: $\text{astep} \leq \text{maximumstep} \times \min(s_{k-1}/s_k, 1)$ from the 2-point secant slope $s$ — shrinks the step approaching a fold, restores it after. <b>false</b> disables. |
| aal_limit_init | 30      | Sentinel magnitude meaning “no Padé pole found yet”.                                                                                                                                                             |

| Parameter                     | Default | Meaning                                                                                                |
|-------------------------------|---------|--------------------------------------------------------------------------------------------------------|
| <code>stall_iter_mult</code>  | 3       | Flag a numerical stall when corrector iterations exceed this $\times$ <code>targetsteps</code> .       |
| <code>step_adapt_denom</code> | 40      | Step-growth denominator: $\text{astep} \times (1 + (\text{targetsteps} - \text{iters})/\text{this})$ . |

## 7.5 Holomorphic degree

Set in the drivers / `main.m`: `degree.act = 15` (active power-series degree), split as `degree.numerator = 8`, `degree.denominator = 7` for the Padé approximant. Changing them changes the Padé order; because this build is pure MATLAB, the new values take effect immediately (no rebuild needed).

## 8 Outputs

**Console:** per-case progress, solution count, and CPU (serial) or wall (parallel) time, followed by a summary table.

**CSV summaries** (written into the run folder):

| Driver                            | CSV file                                  |
|-----------------------------------|-------------------------------------------|
| <code>run_batch.m</code>          | <code>results_summary.csv</code>          |
| <code>run_batch_par.m</code>      | <code>results_par_summary.csv</code>      |
| <code>run_batch_parfeval.m</code> | <code>results_parfeval_summary.csv</code> |

Columns: `case_name`, `cpu_time_sec` (or wall time), `n_solutions`, `status` (OK / ERROR), `error_msg`. These CSV files are run outputs and are ignored by the repository `.gitignore`.

The full solution set is available in the workspace as `Zsave` (each column a solution in the internal variable ordering) after a run; the solver sign-normalises and deterministically orders it (`canonicalize_solutions.m`) so that serial, parfor and parfeval produce identical output for the same case. Antipodal pairs  $\{x, -x\}$  are identified as one solution.

## 9 File map

**Configuration:** `solver_params.m` — single source of truth for every tunable constant (Section 7).

**Setup / preprocessing:** `makeYbus` from MATPOWER (Ybus), `get_quadr_mtrx.m` (power-balance quadratics), `quadr_matrix.m` (per-bus PV/PQ/slack matrices), `Solu.m` (initial point from `runpf`), `MakeEllipse.m` (base-ellipse generation), `Tune_Fac.m` (continuation scaling), `main.m` (reference preprocessing script; its logic is inlined into the drivers).

**Core solver (shared hot path):** `hybrid_traceloops_4_no_mex.m` (outer trace-loop orchestrator; loads `param` from `solver_params.m`, primes the cached operators), `holomorphic_hybrid_5_no_mex.m` (one holomorphic step + consensus pole estimate), `branch_trace_hybrid_4_no_mex.m` (predictor–corrector continuation), `Resolve_no_mex.m` (Newton corrector), `holomorphic_cont_tri.m` (Taylor-coefficient triangular solves), `holomorphic_para_sp.m` (sparse  $H$  builder), `Pade_Apprxmt.m` (Padé construction), `update_V_Pade.m` (Padé evaluation along the arc), `MakeJacobianD.m`

(cached sparse Jacobian), `quad_form_vals.m` (cached constraint-residual evaluator), `MakeJacobian.m` (scalar Jacobian, used by `Tune_Fac`).

**Post-processing:** `canonicalize_solutions.m` (sign-normalise + deterministic ordering).

**Parallel housekeeping:** `cleanup_parallel_artifacts.m` (clears per-worker caches, optionally closes the pool to avoid a Windows/R2022a -batch shutdown crash).

**Drivers:** serial — `runVBook_hybrid_2023.m`, `run_batch.m`; parfor — `runVBook_hybrid_parallel.m`, `trace_equation_worker.m`, `run_batch_par.m`; parfeval — `runVBook_hybrid_parfeval.m`, `trace_equation_worker_const.m`, `trace_equation_worker.m`, `run_batch_parfeval.m`; convenience — `run_merged_case.m` (one case, any mode).

**Case data:** `caseXXX.m` MATPOWER-format test systems.

## 10 Portability and performance

This is the pure-MATLAB build: no compilation, no MATLAB Coder, and no C compiler — it runs unchanged on Windows, Linux and macOS. Every hot-path routine is a plain `.m` file (e.g. `Pade_Apprxmt.m`, `holomorphic_cont_tri.m`), so editing and debugging require nothing beyond MATLAB itself.

If you need more speed on Windows x64, the companion release `HEBCPF_MEX_v3.202606` ships two compiled MEX functions on the hot path (`Pade_Apprxmt` and `holomorphic_cont_tri`) and runs the serial trace roughly  $2\times$  faster, with numerically identical results (verified to  $\sim 10^{-13}$ ). The two builds are otherwise interchangeable: you can develop here and deploy there, or vice versa.

## 11 Troubleshooting

### Undefined function 'runpf'

MATPOWER is not on the MATLAB path. Install and `addpath` it.

### Undefined function 'makeYbus'

MATPOWER is not on the MATLAB path, or the MATPOWER `lib` folder is missing from the path.

### Undefined function 'caseXXX'

Run `addpath(pwd)` from this folder; the case data files live here.

### OSQP warning during runpf

Harmless MATPOWER solver-probe message; `runpf` still converges (equation error  $\sim 0$ ).

### Parallel driver appears to hang at first run

The local `parpool` is starting; this one-time cost is excluded from the reported timing.

### Solution count differs from the expected value

Check the load factor is 1 and that the MATPOWER initial solve (`runpf`) reported success. Note that the pole-estimation, `handback` and `slope_max` settings affect *tracing efficiency and numerical robustness*, not the final solution set on well-behaved cases.

## 12 License and third-party notices

HEBCPF is distributed under the BSD 3-Clause License; see the top-level `LICENSE` file. Some bundled `caseXXX.m` files are copied from, derived from, or modified from MATPOWER and

other public test-system sources. Preserve the per-file attribution notices when redistributing modified versions, and see the top-level NOTICE file for third-party attribution details.

## 13 Citing this solver

If you use results produced by this solver, please cite the **HEBC** paper:

D. Wu and B. Wang, “Holomorphic Embedding Based Continuation Method for Identifying Multiple Power Flow Solutions,” *IEEE Access*, vol. 7, pp. 86843–86853, 2019. doi: [10.1109/ACCESS.2019.2925384](https://doi.org/10.1109/ACCESS.2019.2925384).

BibTeX:

```
@article{wu2019hebc,
  author = {Wu, Dan and Wang, Bin},
  title = {Holomorphic Embedding Based Continuation Method for
    Identifying Multiple Power Flow Solutions},
  journal = {IEEE Access},
  volume = {7},
  pages = {86843--86853},
  year = {2019},
  doi = {10.1109/ACCESS.2019.2925384}
}
```

For citing the software package itself, see the top-level CITATION.cff file.

## Further reading

The method rests on, and is extended by, the following works:

1. B. C. Lesieutre and D. Wu, “An Efficient Method to Locate All the Load Flow Solutions — Revisited,” in *2015 53rd Annual Allerton Conference on Communication, Control, and Computing (Allerton)*, Monticello, IL, USA, pp. 381–388, IEEE, 2015. doi: [10.1109/ALLERTON.2015.7447029](https://doi.org/10.1109/ALLERTON.2015.7447029). (*The elliptical branch-tracing formulation that underlies this solver.*)
2. D. Wu, “Algebraic Set Preserving Mappings for Electric Power Grid Models and Its Applications,” Ph.D. dissertation, University of Wisconsin–Madison, 2017. (*The dissertation that formalises the elliptical / algebraic-set-preserving formulation and specifies the predictor–corrector continuation machinery — the Phase I/II correctors, step-length control, and solution/termination logic — that this solver implements.*)
3. D. Wu, D. K. Molzahn, B. C. Lesieutre, and K. Dvijotham, “A Deterministic Method to Identify Multiple Local Extrema for the AC Optimal Power Flow Problem,” *IEEE Transactions on Power Systems*, vol. 33, no. 1, pp. 654–668, Jan. 2018. doi: [10.1109/TPWRS.2017.2707925](https://doi.org/10.1109/TPWRS.2017.2707925). (*Extends the tracing method to AC optimal power flow.*)
4. B. Wang, D. Wu, X. Su, K. Sun, and L. Xie, “A Long-Term Voltage Stability Margin Index Based on Multiple Real Power Flow Solutions,” in *2023 IEEE Power & Energy Society General Meeting (PESGM)*, Orlando, FL, USA, pp. 1–5, IEEE, Jul. 2023. doi: [10.1109/PESGM52003.2023.10252776](https://doi.org/10.1109/PESGM52003.2023.10252776). (*Defines a voltage-stability margin as the minimum voltage-space distance from the high-voltage solution to all other real power-flow solutions — a direct application of this solver’s output.*)

5. D. Wu and B. Wang, “Influence of Load Models on Equilibria, Stability and Algebraic Manifolds of Power System Differential-Algebraic System,” in *2019 57th Annual Allerton Conference on Communication, Control, and Computing (Allerton)*, Monticello, IL, USA, IEEE, 2019. doi: [10.1109/ALLERTON.2019.8919649](https://doi.org/10.1109/ALLERTON.2019.8919649). (*How load models reshape the solution manifold and its equilibria.*)
6. D. Wu and B. Wang, “Collection of Numerous Power Flow Solutions of Standard IEEE Test Systems,” *IEEE Dataport*, Jul. 2019. doi: [10.21227/24bh-hj72](https://doi.org/10.21227/24bh-hj72). (*The published dataset of reference solution sets for the standard IEEE test systems — useful for validating this solver’s output.*)