HOW TO PROCEED WITH TROUBLESHOOTING

1	VEHICLE BROUGHT TO WORKSHOP				
NEXT					
2	CUSTOMER PROBLEM ANALYSIS (See page IN-26)				
NEXT					
3	PASSENGER AIRBAG ON/OFF INDICATOR CHECK (See page RS-362)				
NEXT					
4	DTCs CHECK (Present and Past DTCs) (See page RS-365)				
(a) Check for DTCs. Result					
	Result	Proceed to			
DTC is ou		A			
DTC is no	DTC is not output.				
	В	O TO PROBLEM SYMPTOMS TABLE			
A					
5	DTCs CHART (See page RS-368)				
NEXT					
6	CIRCUIT INSPECTION				
NEXT					
7	REPAIR OR REPLACEMENT				
7 NEXT					

(a) Clear the DTCs.

NEXT

9 DTC CHECK (Present and Past DTCs) (See page RS-365)

(a) Check for DTCs.

Result

Result	Proceed to
DTC is not output.	A
DTC is output.	В

B Go to step 5

A

10 SYMPTOM SIMULATION (See page RS-361)

(a) Check the passenger airbag ON/OFF indicator condition.

Result

Result	Proceed to
Passenger airbag ON/OFF indicator is operating normally.	A
Passenger airbag ON/OFF indicator (OFF) and SRS warning light come on.	В

B Go to step 5

_A__

11 CONFIRMATION TEST

NEXT

END

RS