

## **FAN**

## **INSPECTION**

- 1. INSPECT FLUID COUPLING ASSEMBLY
  - (a) Check the fluid coupling for damage and silicon oil leakage.

If necessary, replace the fluid coupling.

