R155 MANUAL TRANSMISSION

SST

	00000 00010	Occurs & Octal Barriana	
	09223-00010	Cover & Seal Replacer	
	09308-00010	Oil Seal Puller	
	09309-35010	Transmission Rear Bearing Replacer	
	09316-60011	Transmission & Transfer Bearing Replacer	
999			
	(09316-00011)	Replacer Pipe	
	(09316-00031)	Replacer B	
	(09316-00041)	Replacer C	
	09515-10010	Rear Axle Bearing Replacer	
_	09608-06041	Front Hub Inner Bearing Cone Replacer	
_	09710-30050	Suspension Arm Bushing Replacer	
	09817-16011	Back-up Light Switch Tool	
		<u> </u>	



1			1
OT A	09950-00020	Bearing Remover	
	09950-40011	Puller B Set	
	(09951-04010)	Hanger 150	
	(09952-04010)	Slide Arm	
	(09953-04020)	Center Bolt 150	
	(09954-04010)	Arm 25	
	(09955-04011)	Claw No.1	
	(09955-04051)	Claw No.5	
	(09957-04010)	Attachment	
8			
	(09958-04011)	Holder	
	09950-50013	Puller C Set	
11 8 8 2 2			
	(09951-05010)	Hanger 150	



	(09952-05010)	Slide Arm	T
	(03932-03010)	Olide Allii	
	(09953-05020)	Center Bolt 150	
Commen			
	(09954-05021)	Claw No.2	
OF THE PARTY OF TH			
CILILLE			
	(09957-04010)	Attachment	
	,		
٨			
	09950-60010	Replacer Set	
GENERAL SE			
	(2227 (2222)		
	(09951-00220)	Replacer 22	
(a)			
	(09951-00300)	Replacer 30	
	(0000: 00000)	Tropiaco: CC	
(Θ)			
	(09951-00520)	Replacer 52	
<u> </u>			
	(09951-00570)	Replacer 57	
(a)			
	(09952-06010)	Adapter	
	(5552 55010)		
	09950-70010	Handle Set	
[Don			
N N N N			
	(09951-07100)	Handle 100	

PP