2TR-FE EMISSION CONTROL SERVICE DATA

| Duty vacuum switching valve | Resistance | 1 - 2 | 26 to 30 Ω at 20°C (68°F) | |
|------------------------------|------------|------------------|-----------------------------|--|
| | | 1 - Body | 10 M Ω or higher | |
| | | 2 - Body | 10 $M\Omega$ or higher | |
| Air fuel ratio sensor | Resistance | 1 (HT) - 2 (+B) | 1.8 to 3.4 Ω at 20°C (68°F) | |
| | | 1 (HT) - 4 (AF-) | 10 k Ω or higher | |
| Heated oxygen sensor | Resistance | 1 (HT) - 2 (+B) | 11 to 16 Ω at 20°C (68°F) | |
| | | 1 (HT) - 4 (E) | 10 k Ω or higher | |
| Pressure sensor | Voltage | VC - E2 | 4.5 to 5.5 V | |
| Air switching valve assembly | Resistance | 1 - 2 | 4.5 to 5.5 Ω at 20°C (68°F) | |
| Air pump assembly | Resistance | 1 - 2 | 0.4 to 1.0 Ω at 20°C (68°F) | |



TORQUE SPECIFICATIONS

| Part Tightened | N*m | kgf*cm | ft.*lbf |
|-----------------------------------------------------------|-----|--------|------------|
| Air fuel ratio sensor x Exhaust pipe assembly front | 44 | 449 | 33 |
| Battery x Battery negative terminal | 3.9 | 40 | 35 in.*lbf |
| Heated oxygen sensor x Exhaust pipe assembly tail | 44 | 449 | 33 |
| Air pump assembly x Body | 18 | 184 | 13 |
| Washer jar assembly x Body | 6 | 56 | 49 in.*lbf |
| Air switching valve assembly x Cylinder head sub-assembly | 20 | 204 | 15 |
| Intake pipe insulator x Air switching valve assembly | 20 | 204 | 15 |
| Intake pipe insulator x Cylinder head sub-assembly | 20 | 204 | 15 |
| Exhaust manifold heat insulator No. 1 x Exhaust manifold | 12 | 122 | 9 |
| Charcoal canister x Body | 20 | 204 | 15 |
| Charcoal canister filter No. 2 x Body | 20 | 204 | 15 |

SS