
QUARTER WINDOW GLASS (for Access Cab)

COMPONENTS





REMOVAL

- REMOVE REAR ACCESS PANEL WEATHERSTRIP (See page ED-53)
- 2. REMOVE LAP BELT OUTER ANCHOR COVER (See page ED-53)
- 3. REMOVE REAR DOOR TRIM BOARD SUB-ASSEMBLY (See page ED-53)


4. REMOVE REAR DOOR GLASS SUB-ASSEMBLY

- (a) Apply protective tape to the outer circumference of the quarter window, as shown in the illustration.
- (b) From the interior, insert piano wires between the vehicle body and quarter window, as shown in the illustration.
- (c) When separating the quarter window from the vehicle, be careful not to damage the vehicle's paint or exterior/interior ornaments.

NOTICE:

When separating the quarter window from the vehicle, be careful not to damage the vehicle's paint or exterior/interior ornaments.

(d) Cut through the adhesive by pulling the piano wire around the quarter window.



INSTALLATION

1. CLEAN VEHICLE BODY

- (a) Clean and shape the contact surface of the vehicle body.
 - (1) Using a knife, cut away any rough adhesive on the contact surface of the vehicle body to ensure the appropriate surface shape.

NOTICE:

Be careful not to damage the vehicle body.

Leave as much adhesive on the vehicle body as possible.

(2) Clean the contact surface of the vehicle body with a shop rag saturated with cleaner. HINT:

Even if all the adhesive has been removed, clean the vehicle body.


2. INSTALL REAR DOOR GLASS SUB-ASSEMBLY LH


(a) Using a brush, apply Primer M to the exposed part of the vehicle body.


NOTICE:

- Allow the primer to dry for 3 minutes or more.
- Do not apply Primer M to the adhesive.









- Throw away any leftover Primer M.
- Do not apply too much Primer M.
- (b) Using a brush or sponge, apply Primer G to the edge of the quarter window and contact surface. **Specification**

Area	Measurement
а	5 mm (0.197 in.)
b	20 mm (0.787 in.)
С	26 mm (1.023 in.)

NOTICE:

- Allow the primer to dry for 3 minutes or more.
- Throw away any leftover Primer G.
- Do not apply too much Primer G.

HINT:

If Primer G is applied to any areas other than that which is specified, wipe off the primer with a clean shop rag before it dries.

(c) Apply adhesive.

Adhesive:

Part No. 08850-00801 or equivalent

(1) Cut off the tip of the cartridge nozzle, as shown in the illustration.

HINT:

After cutting off the tip, use all adhesive within the time indicated in the table bellow.

Usage time frame

Temperature	Usage Time Frame
35°C (95°F)	15 minutes
20°C (68°F)	1 hour 40 minutes
5°C (41°F)	8 hours

- (2) Load the sealer gun with the cartridge.
- (3) Apply adhesive to the quarter window as shown in the illustration.

Specification

Area	Measurement
а	8 mm (0.315 in.)
b	12 mm (0.472 in.)
С	13 mm (0.512 in.)

3. **CHECK FOR LEAKAGE AND REPAIR**

- (a) Conduct a leak test after the adhesive has completely hardened.
- (b) Seal any leakage with auto glass sealer.
- **INSTALL REAR DOOR TRIM BOARD SUB-**ASSEMBLY (See page ED-63)
- INSTALL LAP BELT OUTER ANCHOR COVER (See 5. page ED-63)
- **INSTALL REAR ACCESS PANEL WEATHERSTRIP** 6. (See page ED-64)

