

SAT-SAFE-002 Safe Mode Recovery

Use this procedure after an attitude fault. The spacecraft sheds the payload, points at the sun, and waits for ground command.

Recovery path



The diagram shows Fault Detect, then Safe Mode, then Sun Point. Sun point is complete when the solar array current is above 1.5 A.

Signal	Safe-mode value	Meaning
Payload switch	Open	Payload is unpowered
Array current	Above 1.5 A	Sun point is holding
Reaction wheel	Off	Wheels are safed