

CLOWN

Bubble-shooting sleeve — build manual

Squeeze your fingers into your palm and a comet of light runs from your elbow to your fingertips, arriving exactly as bubbles start firing out of your hand. **Two arms, two identical rigs, one trigger per hand.**

Every part is numbered; the assembly steps refer back to those numbers in **[brackets]**. Each part carries **two** quantities — **per arm**, and what to actually **buy** for the whole costume. They are different numbers. Confusing them is how people end up halfway through a build with one glove.

Order this first

Two bubble kits [1] — one blower per hand, and each kit brings a protected cell [12] and a charger.

Two bottles [2] — 24T/30T neck. *Not included in the kit.*

A pair of gloves [6] and a pair of sleeves [7] — test the fabric in a dark room before you commit to either.

Two of every electronic part. The arms are independent; nothing is shared.

THE BUBBLES

1. Bambu Lab Electric Bubble Maker Kit 01 (P6M) — 1 per arm · buy 2

A blower head, a one-way-valve bottle cap, silicone hose and a gravity ball. You are not modifying how it makes bubbles — only taking over the decision of *when*. Each kit also includes a protected cell [12] on a PH2.0 pigtail and a matching USB charger. **The bottle is not included.**

2. Bottle, 24T or 30T neck — 1 per arm · buy 2 + a spare

The reservoir the kit's cap screws onto. Bambu says explicitly: not a drinking bottle. Choose the size deliberately — a full bottle is the heaviest single item on your arm, so this is your main lever on how tiring the costume is.

3. Silicone tube, 3 x 5 mm — buy 1 m

Same size as the hose in the kit. You need it for the mount test in Step 7, which decides where the bottle lives. Stock aquarium tubing; costs almost nothing. Keep the offcut as a field spare.

4. Bubble solution — buy all you can carry

This runs out long before the battery does. It is the actual limit on your night.

THE LIGHT

5. WS2812B LED strip, 60 LED/m, 5V, black PCB, IP65 — 0.4 m per arm · buy 1 m roll

A ribbon where every single light has its own chip inside, so each one takes orders individually down one data wire. That is the only reason a travelling comet is possible — an ordinary strip can only be one colour at a time. IP65 is the clear silicone sleeve that keeps the soap out.

6. Thin, pale, stretchy glove — 1 per arm · buy a pair

The hand strip hides under this. Fabric spreads the light into a smooth glow instead of visible dots — but only if it is thin and pale. Thick or dark fabric, especially leather, swallows almost all of it.

7. Sleeve or arm warmer — 1 per arm · buy a pair

Same job as the glove [6], for the forearm segment. Same fabric rules. Buy both at once and test them together — a glove that glows over a sleeve that does not is a half-lit arm.

THE BRAIN

8. Seed XIAO ESP32-C3 — 1 per arm · buy 2

A complete computer the size of a postage stamp. It watches its own arm's trigger and decides what all 21 lights do, about 60 times a second. You reprogram it over USB-C — with a data cable [34], not a charge-only one.

9. 74AHCT125 level shifter — 1 per arm · buy 2 (get 5)

A translator that also shouts. The brain speaks at 3.3V; the strip is listening for 5V. Usually the strip *sort of* hears it anyway — which is exactly the problem. Leave this out and your lights flicker randomly, normally for the first time once you are in costume.

MOTOR CONTROL

10. N-channel logic-level MOSFET module — 1 per arm · buy 2

An electric switch with no moving parts. The brain can think, but it cannot push enough power to spin a motor, so it flicks this instead and this lets the big current through.

11. 1N5819 flyback diode — 1 per arm · buy 2 (get 10)

A motor is really just a coil of wire, and cutting power to a coil makes it kick a nasty voltage spike backwards. This is a one-way valve that gives the spike a safe loop to burn itself out in. It costs 20 cents; skip it and the MOSFET [10] eventually dies.

POWER

12. Protected 18650 cell — 1 per arm · buy 2 + 2 spares

A rechargeable battery — one comes free with each bubble kit [1], already on a **PH2.0 pigtail**. Keep that pigtail: it is what the kit's charger mates to, so a flat cell swaps pod to charger with no adapter. *Protected* means a guardian circuit cuts it off before you over-drain it. Never substitute unprotected cells. This is strapped to your arm.

13. 18650 sled with wire leads — 1 per arm · buy 2

The slot the battery sits in, so you can swap a flat cell for a fresh one without a soldering iron. Print one with a lid that clicks shut.

14. 5V boost converter module — 1 per arm · buy 2

A pump, but for voltage. The battery only makes about 3.7V and the lights and brain need 5V. Here it only has to carry the lights (~0.3A) because the motor runs straight off the battery, so a small cheap one is genuinely fine.

15. 2A resettable polyfuse (PPTC) — 1 per arm · buy 2 (get 5)

A safety valve that resets itself. If something shorts out, it suddenly becomes very resistant and chokes the current off before anything gets hot. Let it cool and it goes back to normal by itself.

16. 100 kilo-ohm resistors — 2 per arm · buy 4

Two resistors that shrink the battery voltage neatly in half, so the brain [8] can measure it without being damaged. This is what lets the costume warn you that the cell is nearly flat instead of just dying.

SIGNAL CONDITIONING

17. 1000 uF electrolytic capacitor — 1 per arm · buy 2

A tiny water tank for electricity. When a lot of LEDs switch on in the same instant they all gulp power at once; the tank smooths out the gulp so the voltage does not dip. Polarised — the leg with the stripe is negative, and backwards it pops.

18. 330-470 ohm resistor — 1 per arm · buy 2

A speed bump on the data wire. It softens the sharp edge of the signal so it does not bounce back down the wire and garble the message to the first pixel. Skip it and pixel 1 misbehaves while all the others are fine.

THE TRIGGER

19. Snap-action lever microswitch — 1 per arm · buy 2 + 2 spares

A clicky button with a little metal arm sticking off it. **One per hand** — each hand fires its own arm, and nothing crosses the torso. The arm is the whole point: a wide target you can hit mid-performance without looking. It also clicks, so you feel it go.

CONNECTORS — SO IT COMES APART

20. JST-SM pigtail pair, 6-pin — 1 per arm · buy 2 + 1 spare

The **elbow** plug: strip 5V, ground and data, plus the trigger's two wires, plus a second ground. Both the trigger and the motor have to reach the pod from your hand, so both cross *both* joints — which is why this is 6-pin and not 3. Pin 6 is not spare: the elbow run is the longest in the costume, and a second ground cuts the voltage drop.

21. JST-SM pigtail pair, 5-pin — 1 per arm · buy 2 + 1 spare

The **wrist** plug: the strip's three conductors plus this hand's trigger. One pull and the whole glove [6] comes off. Mate it 3-4 cm above the wrist crease, where the skin barely moves — never on the crease itself.

22. JST-SM pigtail pair, 2-pin — 2 per arm · buy 4 + 2 spares

The motor run, one at each joint. Kept off the data line on purpose: an amp of switched PWM bundled against a WS2812 wire is asking for flicker. These two are the only identical pair in the build, and that is safe — they sit on the same net, so cross-mating them just shortens the run.

23. JST-ZH pigtail pair, 2-pin, 1.5 mm — 1 per arm · buy 2 + 2 spares

Goes at the microswitch [19] itself, so a dead trigger is a ten-second swap rather than a soldering job. **It must not be PH2.0.** Every cell [12] ships on a PH2.0 lead, and one wrong plug in a dark room would put 3.7V straight onto GPIO3. ZH is 1.5 mm pitch, PH is 2.0 — they physically will not mate.

24. Dielectric grease — buy 1 small tube

Non-conductive waterproof goo. A smear in each connector shell stops soap residue corroding the contacts over a season. The alternative is intermittent faults you will chase for hours.

WIRE AND MATERIALS

25. Silicone hookup wire, 22-26 AWG — buy one assortment

Wire with soft rubbery insulation instead of stiff plastic. It survives thousands of bends. Ordinary wire — especially solid-core — snaps at the elbow and wrist within a few hours of wearing it. Thicker for power, thinner for signals.

26. Heat-shrink tubing, assorted — buy one assortment

Plastic sleeve that shrinks tight when heated, sealing and insulating each solder joint. Slide it onto the wire **BEFORE** you solder. Everyone forgets once.

27. Protoboard, small — 1 per arm · buy 2

The perforated board the pod's components sit on. Nothing exotic — a 4 x 6 cm piece per arm is plenty.

28. Hot glue, or clear RTV silicone — buy 1

Seals the cut ends of the strip [5] against soap. Easy to forget when ordering and annoying to be without at Step 3.

29. Needle and thread, or fabric glue — buy 1

For sewing the strip channels into the glove [6] and sleeve [7]. A channel the strip can slide inside — not glued down flat.

30. Fabric marker pen — buy 1

For marking where your finger pads land on your palm in Step 1. That mark is where the trigger [19] goes.

TOOLS — ONE EACH, NOT ONE PER ARM

31. Multimeter — buy 1

Not optional. Polarity before every first power-up, continuity for tracing a dead segment, and actual current draw. Minimum spec: DC volts, AC volts, DC current to 2A on a **fused** input, resistance, and **continuity with a fast audible beeper** — that beeper is what you will live in. Capacitance is worth having. Auto-ranging, backlight and hold, because you will be under a table.

32. Soldering iron, flux-core solder, flux pen — buy 1

Buy **flux-core** solder, 0.8 mm; solid wire with no flux is miserable. The flux pen is separate — the IP65 strip pads are the grubbiest joints here and want extra. On leaded vs lead-free: **the fumes that make you feel ill are the flux, not the lead**, so ventilate either way. The real lead risk is ingestion, closed by washing your hands. Lead-free needs a hotter iron and wets worse, which bites on strip pads; 63/37 is more forgiving. Either is defensible.

33. Thermal camera — buy 1 (borrow it)

Optional, genuinely useful. Turns Step 6's "touch it and see if it is warm" into a measurement, and catches what a fingertip misses: a boost [14] running hot from a short downstream, a MOSFET [10] that turned out not to be logic-level, a strip section drawing more than its neighbours. One borrowed session is plenty.

34. USB-C cable, data capable — buy 1

A charge-only cable looks identical and will cost you half an hour of confusion before you think to suspect it.

35. 3D printer — buy 1

For the trigger plate, the battery sled [13], the controller pod and the bubbler mount. You already have one.

The one mistake that costs a board

The **trigger pigtail [23] must not be PH2.0.** Every cell [12] ships on a PH2.0 lead, so an identical trigger plug is one wrong connection away from putting 3.7V onto GPIO3.

And rework the kit's motor lead [1] off PH2.0 to SM 2-pin [22]. As shipped, the cell mates straight to the motor — bypassing the MOSFET [10], so the trigger does nothing and the blower simply runs.

Assembly

Read this whole manual once before picking up the soldering iron [32]. Several steps are much easier if you know what is coming — notably that heat-shrink [26] goes on *before* you solder, and that you bench-test everything *before* anything goes inside a glove [6].

Budget a full afternoon for the first arm. The second takes about half as long, because by then you know what you are doing.

What you are building

Two arms. Each arm is four modules that unplug from each other. Nothing is soldered end to end across a joint — that is what lets you get out of the costume alone, with soapy hands.

Module	Holds	Unplugs at
Pod — upper arm	brain [8], boost [14], level shifter [9], MOSFET [10], fuse [15], sled [13]	battery plug + straps
Sleeve — forearm	forearm strip [5], 15 px	elbow: SM 6-pin [20] + SM 2-pin [22]
Glove — hand	hand strip 6 px, this hand's trigger [19]	wrist: SM 5-pin [21]
Bubbler	bottle [2], cap, hose, blower head	wrist: SM 2-pin [22] + its strap

Steps 1–10 build one arm. Step 11 is the second arm. Step 12 is the costume — the two arms together, and how you get in and out of it.

Safety, briefly but seriously

The cell [12] is lithium. Never short its terminals, never charge a puffy or damaged cell, and do not leave it charging unattended.

Check polarity with the multimeter [31] before you connect the battery the first time — reversed power destroys the brain [8] and the strip [5] instantly and permanently.

Solder somewhere ventilated. The fumes are flux, not lead — unpleasant whichever solder [32] you bought.

The connector rule you will use constantly

Battery out before you mate or unmate anything. Feeding data into an unpowered WS2812 strip [5] pushes current through its input protection diodes, which is the classic way to kill pixel 0 — and that is exactly what happens if you plug the glove in while the pod is live. Unplug the cell [12] first, every time. It takes one second and becomes automatic quickly.

Step 1 — Measure your arm

Put on the glove [6] and sleeve [7] and hold your arm out in the finger-gun pose. Measure and write down:

- **Elbow to wrist crease** — typically about 25 cm.
- **Wrist crease to knuckles**, across the back of the hand — about 10 cm.
- **Where your middle and ring finger pads land** on your palm when you squeeze. That is where the trigger [19] goes. Mark it with a fabric pen [30].

Convert the first two into pixel counts. At 60 LED/m each pixel on the strip [5] is **1.67 cm**:

```
forearm pixels = forearm cm / 1.67
hand pixels    = hand cm / 1.67
```

That is usually about **15** forearm pixels and **6** hand pixels. Round down. **Then subtract about 4 cm from the forearm figure** — the wrist umbilical and its connector [21] need to live in the last few centimetres of forearm, just above the crease where the skin barely flexes.

Step 2 — Cut the strip

The strip [5] has marked cut lines between every pixel, with copper pads either side. **Cut through the middle of the pads**, not beside them — you need pad left on both pieces to solder to. Cut two pieces to the pixel counts from Step 1.

Check the arrows before you cut

The strip has small printed arrows showing which way data flows. Data must run **elbow to fingertips**, so both pieces need their arrows pointing the same way, toward your fingers. Getting this backwards is the most common build mistake and the fix is unsoldering everything. Mark the elbow end with tape — that end is pixel 0.

Why two pieces? Your wrist bends constantly, and a single continuous strip across that joint cracks its internal copper traces within hours of wear. Everything past the crack then goes dark. The flexible umbilical in Step 3 absorbs that movement instead.

Step 3 — Build the wrist umbilical

This is the plug that lets the glove [6] come off on its own. It carries **five conductors**: the strip's 5V, ground and data, plus this hand's two trigger wires. Use a **JST-SM 5-pin pigtail pair** [21]. Decide the pin convention now and keep it identical on both arms.

SM-5 pin	Carries
1	Strip 5V
2	Strip GND
3	Strip data
4	Trigger
5	Trigger return (to ground at the pod)

Sleeve side

- Slide heat-shrink [26] onto every wire **now**, before soldering.
- Solder short silicone leads [25] to the forearm piece's **output** end — 5V, GND and **DO** — then on to pins 1-3 of one pigtail half.
- Pins 4-5 get two thin wires long enough to run all the way **up the forearm to the elbow**. They are the trigger's path to the pod.
- Shrink everything down, then seal the exposed strip end with hot glue [28] or clear silicone. That is the soap-proofing.

Glove side

- Solder pins 1-3 of the other half to the hand piece's **input** end: 5V to 5V, GND to GND, pin 3 to **DI**.
- Pins 4-5 get two wires long enough to reach the palm, ending in the **female half of a JST-ZH 2-pin** [23]. That is where the microswitch plugs in at Step 5.
- Shrink, and seal the strip end the same way.

Where the connector sits, and why

Mate the pair 3-4 cm above the wrist crease, on the forearm. That skin barely moves; the crease itself is the worst possible place for a rigid 20 mm plastic body. The glove-side wire is the flex element — leave a **service loop** so it is never under tension at full extension.

Keep the whole umbilical short. Every centimetre between the last forearm pixel and the first hand pixel is dark arm the comet has to cross. Around 8 cm is fine; 15 cm reads as a gap. **Measure the finished pixel-to-pixel distance and write it down** — it becomes GAP_PX in Step 8.

Step 4 — Build the controller pod

This all lives on a small piece of protoboard [27] that sits on your **upper arm**, above the soap spray.

From	To	Notes
Battery [12] + (PH2.0)	Polyfuse [15], then everything else	Fuse goes first, right at the cell
Battery [12] – (PH2.0)	Common ground	Everything shares this
Battery + (after fuse)	Boost [14] IN+	
Boost [14] OUT+ (5V)	XIAO [8] 5V pad, 74AHCT125 [9] Vcc, elbow SM-6 [20] pin 1	
Battery + (after fuse)	Motor +, via elbow SM-2 [22]	Motor runs direct from the cell , not from 5V
Motor – (via elbow SM-2)	MOSFET [10] output	

From	To	Notes
XIAO D2 (GPIO4)	MOSFET [10] gate input	
XIAO D10 (GPIO10)	74AHCT125 [9] input	
74AHCT125 [9] output	Resistor [18], then elbow SM-6 pin 3	Resistor at the connector end
XIAO D1 (GPIO3)	Elbow SM-6 pin 4	Trigger, arriving from the hand
Elbow SM-6 pin 5	Common ground	Trigger return
XIAO D0 (GPIO2)	Midpoint of the two 100k resistors [16]	Battery monitor

The pod's two outward plugs

Everything the pod sends down the arm leaves through exactly two connectors:

Plug	Pins
SM 6-pin [20]	1 strip 5V · 2 strip GND · 3 strip data · 4 trigger · 5 trigger return · 6 second ground
SM 2-pin [22]	1 motor + (battery, after fuse) · 2 motor – (MOSFET output)

- **Pin 6 is not spare, it is a job.** The elbow run is the longest in the costume and carries the whole strip's current. A second ground conductor cuts the voltage drop and gives the data line a better return path. Tie it to common ground at both ends.
- **The motor gets its own plug on purpose.** Roughly an amp of switched PWM bundled against a WS2812 data line is asking for flicker. Twist the motor pair.

The battery monitor divider

Battery + (after fuse) —[100k]—+—[100k]— Ground
 |
 XIAO D0

The midpoint sits at exactly half the cell voltage, which is safely inside what the brain [8] can measure.

Also fit

- The **1000 uF capacitor [17]** across the strip's 5V and ground, physically close to the elbow connector. Watch polarity — the striped leg is negative.
- The **1N5819 diode [11]** directly across the motor's two terminals at the blower end, banded end to **positive**. Backwards it is a dead short, so check this one twice.

Keep the cell on its factory plug

The 18650 [12] arrives on a **PH2.0 pigtail**, and the kit's USB charger mates to the same connector. Fit the matching half at the pod and you get a clean swap: pull the flat cell, plug it straight into the charger, plug a fresh one in. No adapters, no rework.

PH2.0 must be the only PH connector in the whole build. See Step 5.

Three rules that matter

1. Everything shares **one common ground** — brain [8], strip [5], level shifter [9], MOSFET [10], boost [14] and cell [12]. Skipping this causes bizarre, hard-to-diagnose behaviour.
2. **Do not use D8 or D9** (GPIO8/GPIO9) for anything. They are boot pins and the board will not start reliably.
3. **Leave the USB-C port reachable** when you design the printed pod, and use a **data-capable** cable [34]. You will reflash this far more often than you expect.

Step 5 — Wire this hand's trigger

Each hand has its own trigger, firing its own arm. Nothing crosses the torso. You are wiring one of two identical, independent triggers.

- Solder two lengths of thin silicone wire [25] to the microswitch's **COM** and **NO** (normally open) terminals.
- Terminate them in the **male half of a JST-ZH 2-pin [23]** — the mate to the one you left on the glove side of the umbilical in Step 3.

- Mount the switch [19] on a small printed plate [35], positioned so the **lever** sits under your middle and ring finger pads at the spot you marked in Step 1.

Orient the lever so a natural squeeze presses across its length. You should be able to fire it with your eyes closed, in one motion, every time. If you catch yourself aiming, reposition the plate until you do not.

Why the switch gets its own tiny plug: the field kit carries a spare microswitch. Without this pigtail, "spare" means "spare, if you also brought a soldering iron." With it, swapping a dead trigger mid-event is a ten-second job.

Why ZH and not PH

The trigger pigtail must not be PH2.0. Every cell [12] in this build ships on a PH2.0 lead. If the trigger used the same connector, one wrong plug in a dark room puts **3.7V directly onto GPIO3** — a dead pin, quite possibly a dead XIAO [8].

JST-ZH [23] is 1.5 mm pitch; PH is 2.0 mm. They physically will not mate. That incompatibility is the entire reason for the choice — do not "simplify" it later by standardising on one connector.

Step 6 — Bench test, before anything goes in the glove

Do not skip this step

Sewing everything into a glove [6] and *then* discovering a reversed data arrow is genuinely miserable. Test it flat on the table first, with every connector mated.

- **Check polarity with the multimeter [31].** Battery + and – where you expect; boost [14] output close to 5.0V. Only then connect the brain [8].
- **Beep through every connector, pin by pin.** A pigtail with a crimp that did not seat looks perfect and works intermittently. Find it now, not at the venue.
- Power up. You should get the dim breathing idle glow.
- Press the microswitch [19] by hand. The comet should launch from the **elbow** end and travel to the **fingertip** end, and the motor should spin.
- If the comet runs backwards, the strip pieces are reversed. **Fix it in the wiring, not in the code** — both arms run identical firmware and that is worth a resolder.
- Let it run five minutes, then check for heat.

Checking for heat

Touch the boost [14] and MOSFET [10]. Warm is fine; too hot to touch means power down and look for a short.

If you can borrow a thermal camera [33], use it here instead. It turns this from a fingertip guess into a measurement, and shows you what a fingertip misses: a boost running hot because something downstream is shorted, a MOSFET that turned out not to be logic-level and is dissipating the difference, or a strip section drawing more than its neighbours. One borrowed session is plenty.

Step 7 — Fit the bubbler

First, understand what you actually have. The kit [1] is not one object — it is a bottle [2], a cap with a one-way valve, and a blower head, joined by silicone hose:

- **~50 mm of hose inside the bottle**, ending in the blue **gravity ball**. The ball sinks, so the pickup stays in solution at any arm angle — even inverted.
- **~50-70 mm of hose outside the cap**, feeding the blower head.

So the heavy thing (the bottle) and the thing that must point past your fingertips (the blower head) **do not have to be in the same place**. That opens up a much better mount — if the blower can pull solution far enough.

The hose test — do this before you commit to a mount

Twenty minutes, one length of 3 x 5 mm silicone tube [3], and it decides the whole mount design. Do it the day the kit arrives, before any of the soldering above.

1. Assemble the kit as supplied and confirm it makes bubbles.
2. Replace the *outside* hose with about **150 mm** of 3 x 5 tube.
3. Run it again, held roughly the way your arm will hold it.

Does it still make bubbles at the same rate?

If it PASSES — Mount C

Bottle on the forearm, blower head at the knuckles pointing past your fingertips.

Bubbles still appear to come from your fingers, so the comet illusion is intact — and the heaviest item on the arm moves off the end of the lever, where it was costing you most.

This is the better build if you can get it.

If it FAILS — Mount A

Bottle and blower head both on the back of the hand, exactly as the kit intends, nozzle past the fingertips. Works as shipped, no modification, no risk.

Manage the weight instead: **run the bottle half-full** (you carry refills anyway); mount the bottle body back toward the wrist with the cap forward, to shorten the lever arm; and anchor to a **wrist strap**, not glove fabric — a glove will not hold 200 g swinging for an evening.

Either way

- Check MakerWorld for existing mounts from the kit's collection as a starting point. Community CAD for the cap thread and the blower sleeve already exists.
- **The bubbler is its own module.** Give it a quick-release strap, and make sure nothing about its mount bridges the wrist — a rigid bottle spanning that joint means the glove [6] cannot come off without removing the bottle first.
- **Rework the motor lead.** The kit ships the motor on a **PH2.0 female** plug that mates straight to the cell [12]. Cut it off and fit a **JST-SM 2-pin** [22]. This is not cosmetic: leave it and the cell can power the motor directly, bypassing the MOSFET [10], and the trigger does nothing.
- Use silicone wire [25] for the motor run; it flexes constantly.
- A longer hose holds more solution, so dribble on shutdown gets slightly worse. The silicone sleeve over the cap's protrusion — the one-way valve — is what stops it emptying into your bag.

Step 8 — Flash the firmware

- Install the Arduino IDE, then add ESP32 board support (Boards Manager, search esp32, install the Espressif package).
- Install the **FastLED** library from the Library Manager.
- Select board XIAO_ESP32C3.
- Open firmware/clown_arm/clown_arm.ino.
- **Edit the layout constants** at the top to match your measurements.
- Plug in USB-C [34] and upload. If it fails, hold BOOT while plugging the cable in.

```
constexpr int FOREARM_PX = 15; // your forearm pixel count
constexpr int HAND_PX    = 6;  // your hand pixel count
constexpr int GAP_PX     = 5;  // umbilical length / 1.67 cm
```

GAP_PX is the measured pixel-to-pixel distance across the umbilical, from the last forearm pixel to the first hand pixel, divided by 1.67 cm. Measure the finished assembly from Step 3 — *including the connector body* [21], which is most of it. About 8 cm gives GAP_PX = 5. Guessing here is what makes the comet look like it stumbles at the wrist.

Flash the identical sketch to both arms. There is deliberately no left/right setting — as long as pixel 0 is at the elbow on each arm, the mirroring is physical only.

Step 9 — Tune the timing

This is the step that makes the whole effect work, and it can only be done on the finished arm. The goal: **the comet reaches your fingertips at the exact moment the first bubble appears**. When it is right, the light looks like it is *causing* the bubbles. Wrong by even 100 ms and it just looks like lag.

- Film yourself firing it in slow motion — any modern phone does 120 or 240 fps.
- Watch it back frame by frame. Does the comet arrive early or late?

- Adjust COMET_TRAVEL_MS: comet arrives **before** the bubbles, increase it; **after** the bubbles, decrease it.
- Reflash and film again. Expect three or four rounds.

The default is 250 ms. Your real number depends on how fast your particular blower [1] spins up, which is why it is guesswork until you measure it. **If you built Mount C, expect a slightly longer number** — a 150 mm feed hose takes marginally longer to prime than a 60 mm one, and that delay lands between the trigger and the first bubble.

Step 10 — Mount into the glove and sleeve

Hiding the strip [5] under fabric is an upgrade, not a compromise — the fabric diffuses the pixels into one smooth continuous streak instead of visible dots. But it only works if the fabric cooperates.

Test the fabric before you commit

Hold a powered section of strip [5] under the glove [6] in a dark room. Thin, pale, stretchy fabric glows beautifully; thick or dark fabric, especially leather, swallows almost all of it. If you cannot see it clearly, no firmware setting will rescue it — get a different glove. **Test the sleeve [7] at the same time**; there is no point in a glove that glows over a sleeve that does not.

- Run the strip across the **back of the hand**, over the knuckles. Never the palm — that is where the trigger [19] is and where you grip things.
- Stop short of the fingertips. The blower head needs that space, and finger joints flex too much for strip to survive.
- Sew a **fabric channel [29]** for the strip to sit in rather than gluing it down flat. The channel lets it slide as your hand flexes; glued-taut strip tears itself off, or tears the glove.
- MAX_BRIGHTNESS is preset high to punch through fabric. You can raise it further for thicker gloves, but current draw climbs with it and battery life drops.

Connectors and strain relief

The connector is never the anchor. Tack the cable to the garment on *both* sides of every plug, so a snag pulls the tack rather than the latch. Leave a **service loop** either side.

A smear of **dielectric grease [24]** in each shell keeps soap residue from corroding the contacts over a season. And position the mated plugs where a tight sleeve will not press them into your skin — a 20 mm plastic body under a cuff for six hours is uncomfortable.

Step 11 — Build the second arm

Repeat Steps 1 to 10. Two things to be careful about:

- **Pixel 0 goes at the elbow on this arm too.** It is tempting to mirror the wiring along with the physical build. Do not. Identical wiring means identical firmware means one thing to maintain.
- **Keep the same SM-5 [21] and SM-6 [20] pin conventions.** If arm A puts the trigger on pins 4-5 and arm B puts it on pins 1-2, then spares are not spares, and one wrong plug at an event costs you a board. Write the pinout on a bit of tape inside each pod.

Step 12 — Assemble the costume

Both arms exist. This step is about the thing you actually wear.

Both-arms checkout

- **Cells [12] out of both pods.**
- Mate every connector on both arms. Count them: **four per arm** — elbow SM-6 [20], elbow SM-2 [22], wrist SM-5 [21], wrist SM-2 [22] — plus the ZH-2 [23] at each microswitch.
- Cells in. Both arms should show the idle glow.
- **Fire each hand separately.** Left trigger drives the left arm only; right drives right only. If one trigger fires the other arm, you have crossed something — there is no cross-arm wiring in this design.
- Fire both at once. Watch for either arm dimming or glitching. They are electrically independent and should not interact at all; if they do, suspect a shared ground you did not intend.
- Run both for the length of a bottle of solution [4]. That is your real duty cycle.

Getting into it — cells go in LAST	Getting out of it — cells come out FIRST
1. Pods on the upper arms, strapped, cells out. 2. Sleeves on. Mate elbow SM-6 and SM-2 each side. 3. Gloves on. Mate wrist SM-5 each side. 4. Bubblers strapped on, mate wrist SM-2, bottles filled. 5. Cells in. Check both idle glows before you walk out.	1. Cells out. Both arms are now dead and safe to unplug. 2. Wrist SM-2 + bubbler strap → bubblers off, bottles upright. 3. Wrist SM-5 → gloves peel off. 4. Elbow SM-6 + SM-2 → sleeves come off. 5. Pod straps.

Four releases per arm, none needing a second person or a flat surface.

The test that matters

Can you get out of it alone, in a bathroom, with soapy hands, in under a minute?

If not, something is still soldered that should not be, or a strap is fighting a connector. Fix it before the event, not at it.

Care afterwards

- **Cells out for storage.** Never store the costume with cells connected.
- Rinse the blower head and cap in warm water — dried bubble solution glues the one-way valve shut.
- Leave the silicone sleeve on the cap protrusion so the bottle does not empty into your bag.
- Wipe soap residue off any connector that got sprayed, and re-grease it [24].

Troubleshooting

Symptom	Likely cause
Nothing lights at all	Check common ground. Check boost [14] output is about 5V. Check strip DIN is on the <i>input</i> end — follow the arrows.
Nothing lights, and it worked yesterday	Check every connector is fully latched. A half-seated SM plug looks mated.
Works until you move your arm	Unseated connector, or a crimp that did not take. Beep through each pin while wiggling the cable.
First pixel wrong colour, rest fine	Missing or wrong-value data resistor [18] .
Pixel 0 died after a reconnect	Strip was plugged in live. Cell [12] out before mating , every time.
Random flickering, especially when moving	Missing level shifter [9] , or a loose ground. Check SM-6 [20] pin 6 is actually tied to ground at both ends.
Comet runs fingertips to elbow	Strip [5] is reversed. Fix the wiring, not the code.
Comet jumps or stalls at the wrist	GAP_PX does not match your measured umbilical length.
Colours wrong, red and green swapped	Change GRB to RGB in the addLeds line.
Motor whines audibly	PWM frequency dropped below 20 kHz — check MOTOR_PWM_HZ.
Motor does not spin	MOSFET [10] gate not on D2, or it is not a logic-level part.
Motor runs constantly, trigger does nothing	Motor still on its factory PH2.0 lead, plugged straight to the cell. Rework it to SM-2 [22] — Step 7.
Everything dies when the motor starts	Cell [12] sagging, or the polyfuse [15] tripping. Check the charge.
Works, then dies after a few minutes	Cell [12] protection circuit cutting out. Recharge or swap.
Elbow pixel pulsing red	Low-battery warning. Swap the cell [12] .
One trigger fires the other arm	Not possible by design — you have cross-plugged two arms. Check each arm is self-contained.
Board will not accept uploads	Hold BOOT while plugging in USB. If the port is not recognised at all, suspect a charge-only cable [34] .
Strip goes dark past the wrist	Cracked trace or failed umbilical joint — the failure the umbilical exists to prevent. Swap in your spare.
Bubbles weak or intermittent	Gravity ball not sitting in solution, or the feed hose [3] is too long. See the Step 7 hose test.
Bubbles stop but the motor runs	Bottle [2] empty, or dried solution in the one-way valve. Rinse the cap.

Changing how it behaves

The whole point of the strip [\[5\]](#) is that every pixel takes orders individually. Everything you would normally want to change lives in one marked block at the top of the sketch — edit, reflash over USB-C, done.

Constant	Changes
THEME_HUE	The comet's colour, 0-255 around the colour wheel
COMET_TRAVEL_MS	Comet speed, and its sync with the bubbles
COMET_REPEAT_MS	How rapid-fire the stream is while held
COMET_FADE	Tail length — higher is shorter
MAX_BRIGHTNESS	Overall brightness, for your glove's fabric
IDLE_BRIGHTNESS	Resting glow. Set to 0 for fully dark when idle
MOTOR_RUN_DUTY	Bubble rate
VBAT_WARN_MV	When the low-cell warning starts

The XIAO [\[8\]](#) has Wi-Fi and Bluetooth sitting unused, already paid for. Natural next steps, in rough order of effort: more patterns with a long-press to cycle them; **ESP-NOW** so either arm's trigger can *also* fire the other for a two-handed blast — note that is **additive**, each hand keeps its own trigger and its own arm; and a small web page served by the board so you can change colour and speed from your phone without a laptop.

Field kit

What to carry when you actually wear this. Everything here now swaps **without a soldering iron** — that is what the connectors bought you:

- A spare charged cell [\[12\]](#) per arm, on its PH2.0 pigtail.
- A **pre-made spare wrist umbilical** [\[21\]](#) — genuinely swappable now that both ends are connectors.
- A spare microswitch [\[19\]](#), already on its ZH-2 pigtail [\[23\]](#).
- One spare SM pigtail pair of each size [\[20\]](#) [\[21\]](#) [\[22\]](#).
- **Extra bubble solution** [\[4\]](#). This runs out long before the battery does.
- Spare 3 x 5 silicone tube [\[3\]](#), in case a feed hose splits.
- A solder pen [\[32\]](#), for repairs you cannot connector your way out of.
- A small screwdriver and some electrical tape.