

BEFORE STARTING ENGINE	
Preflight Inspection	COMPLETE
Main Entry Door	CLOSED & LATCHED
Seats and Seatbelts	SECURE
Passenger Briefing	COMPLETE
Glare Shield	STOWED
MAN OVRD Lever	STOWED
POWER Lever	IDLE
TO PREVENT DAMAGE TO ENGINE CONTROLS, DO NOT MOVE THE POWER LEVER AFT OF THE IDLE GATE WITH ENGINE NOT RUNNING.	
PROP Lever	FEATHER
COND Lever	FUEL CUTOFF
Climate Controls	AS REQUIRED
LIGHTS and ICE Switches	MIN. REQUIRED
BATT 1 & BATT 2 Switches	ON
BATT 1 & BATT 2 Voltages	24.2 V MINIMUM
Fuel-On-Board Totalizer	FOB SYNC
Flight Controls	FREE & CORRECT
Autopilot	TEST
Stall Prevention System	TEST
Landing Field Elevation	VERIFY/SET
Avionics/Navigation	SET
Weather & NOTAMS	CHECK
Altimeters	SET
Clearance Delivery	CHECK
Transponder	AS REQUIRED

STARTING ENGINE	
Exterior Lights	AS REQUIRED
Propeller Area	CLEAR
FUEL TANK SELECTOR Knob	LEFT
Pre-Start Switches	ALL ON
START Switch	PRESS & RELEASE
Oil Pressure	VERIFY RISE
NG	12% MINIMUM
NG	VERIFY STABLE ABOVE 51%
<i>If oil pressure does not rise or NG does not reach minimum speed:</i>	
DISCONTINUE ENGINE START	
<i>If NG stabilizes below 51% or ITT at idle approaches 750°C:</i>	
COND Lever...HIGH	

AFTER START/BEFORE TAXI	
IGNITER Switch	AUTO
PRE-TAXI Switches	ALL ON (EXCEPT PRESSURIZATION)
Crew Oxygen Masks	PRESSURIZED
Climate Controls	AS REQUIRED
PROP Lever	MAX RPM
COND Lever	HIGH
ALTN AMP Indicator	ZERO
TAXI Light	ON
Brakes	CHECK
Flight and Standby Instruments	CHECK
Taxi Instructions	CHECK

BEFORE TAKEOFF	
De-Ice Boot System	TEST
<i>(1500 RPM, prior to flight into icing conditions)</i>	
Propeller Overspeed Governor	TEST
<i>(first flight of day)</i>	
Inertial Separator	TEST
<i>(prior to flight into icing conditions)</i>	
Engine Instruments	NORMAL
Flight Controls	FREE & CORRECT
Trims	SET FOR TAKEOFF
Flaps	T/O
Fuel Quantity, Balance	CHECK
Avionics / Navigation	SET
PRE-TAXI Switches	CHECK ON
SYSTEMS Switches	CHECK OFF
PROP Lever	MAX RPM
Autopilot and Yaw Damper	OFF
TO/GA Takeoff Check	COMPLETE
Takeoff Briefing	COMPLETE

TAKING RUNWAY	
IGNITER Switch	ON
PITOT STALL HT Switch	ON
External Lights	AS REQUIRED
CAS Messages	NO RED OR AMBER MSGS

TAKEOFF / CLIMB	
Rotate	90 KIAS
Brakes	APPLY BRIEFLY
Landing Gear	UP
Flaps	UP
Best Rate of Climb Speed	AS REQUIRED
<i>(VY 150 to FL240 then 140)</i>	
Trim or Yaw Damper	SET
IGNITER Switch	AUTO
Engine Instruments	MONITOR
External lights	AS REQUIRED
Pressurization	CHECK

CRUISE	
POWER Lever	MAXIMUM CRUISE POWER OR LESS
PROP Lever	AS DESIRED
Engine Instruments	MONITOR
Pressurization	MONITOR
Fuel Quantity, Balance	MONITOR
ICE Switches	AS REQUIRED
Guard Frequency	MONITOR

ARRIVAL / DESCENT	
PROP Lever	MAX RPM
Landing Field Elevation	CHECK
Fuel Quantity, Balance	MONITOR
Arrival	SELECTED
Weather & NOTAMS	CHECK

APPROACH	
PROP Lever	MAX RPM
COND Lever	HIGH
IGNITER Switch	ON
Landing Lights	ON
Altimeters	SET
Pusher Ice Mode Alert	CHECK IF ACTIVE
Approach and Landing Brief	COMPLETE

BEFORE LANDING	
Flaps	SET
Landing Gear	DOWN
Brakes	TEST
Yaw Damper	OFF
Rudder Trim	CENTER
<i>Approach Speeds:</i>	
<i>Flaps UP: 115 KIAS (Normal Mode)</i>	
<i>Flaps T/O: 110 KIAS (Normal Mode), 122-133 KIAS (Pusher Ice Mode)</i>	
<i>Flaps FULL: 95 KIAS (Normal Mode)</i>	

AFTER LANDING	
Lights	AS REQUIRED
PITOT STALL HT Switch	OFF
IGNITER Switch	AUTO
Flaps	UP
DE-ICE BOOTS Switch	OFF
INERT SEP Switch	OFF
Flight Plan	CANCEL

SHUTDOWN	
POWER Lever	IDLE
COND Lever	LOW
PROP Lever	FEATHER
Lights	AS REQUIRED
Climate Controls	AS REQUIRED
PRE-TAXI Switches	ALL OFF
Engine Cooldown	COMPLETE
COND Lever	FUEL CUTOFF
After Ng is below 10%:	
L & R FUEL PUMP Switchess	OFF
Fuel Selector	LEFT
Flight Plan	CANCEL
BATT 1 & BATT 2 Switches	OFF