

Yükleme için:

https://www.labcenter.com/downloads/

Tutorial için:

https://labcenter.s3.amazonaws.com/downloads/Tutorials.pdf





The Limitations of the demonstration version are as follows:

- ✓ Not time limited!
- ✓ Extensive set of sample designs included to help you evaluate all aspects of the software.
- ✓ You can write your own software to run on existing sample designs for evaluation purposes.
- × You can only print Schematics and Layouts from the sample designs.
- × You cannot save your work.
- × You cannot simulate your own microcontroller designs.

Please note using a download manager or accelerator may corrupt the file.

Download the Demonstration version here.





Welcome to Proteus 8 Demonstration Setup Wizard

The Setup Wizard will install Proteus 8 Demonstration on your computer. Click Next to continue or close the window to exit the Setup Wizard.

Next >

X

Read the Labcenter Electronics Licence Terms

To continue you must read and accept the terms of this agreement. If you do not want to accept the Labcenter Electronics Licence Terms, close this window to cancel the installation.



PROTEUS PROFESSIONAL LICENCE AGREEMENT

This End-User License Agreement ("EULA") is a legal agreement between you (either an individual or a single entity) and Labcenter Electronics Ltd ("Labcenter"). The SOFTWARE(s) identified above, which includes the Documentation, any associated SOFTWARE components, any media, any printed materials, is referred to as "Software". By installing, copying, or otherwise using the Software, you agree to be bound by the terms of this EULA. If you do not agree to the terms of this EULA, do not install or use the Software.

1. LICENCING

✓ I accept the terms of this agreement.

< Back

Next >



Choose the installation you want




Typical


Installs the most common program features. Recommended for most users.





Custom


Allows users to choose which program features will be installed and where they will be installed. Recommended for advanced users.















Next


Cancel


Help


Back


15








































Shows the currently loaded components.


2 Message(s)














Message

- 1990-2021. Release 8.12.00 (Build 30713) (C) Labcenter Electronics
- Compiling design 'C:\Users\BAP_DR\Documents\lab0.pdsprj'.
- Netlist compilation completed OK.
- Netlist linking completed OK.
- Partition analysis completed OK.
- Simulating partition 1
- PROSPICE 8.08.00 (Build 29194) (C) Labcenter Electronics 1993-2021.
- € Loaded netlist 'C:\Users\BAP_DR\AppData\Local\Temp\LISA4777.SDF' for design 'lab0.pdsprj'.
- ▲[SPICE] singular matrix: check node #\$IDC AMMETER#0004_IP1#branch.
- [SPICE] singular matrix: check node #\$IDC AMMETER#0004 IP1#branch.
- ▲[SPICE] Gmin stepping failed
- SPICE] singular matrix: check node #\$IDC AMMETER#0004 IP1#branch.
- ▲[SPICE] Source step [0 of 120] failed: source factor = 0.0000
- ▲[SPICE] (null).
- Real Time Simulation failed to start.



