


Revision 07.06.18



Controls

- **Volume** Sets the overall output volume
- **Bias** External bias control
- **Fuzz** Controls the level of fuzz
- **Highs** Controls the high end frequencies (post fuzz)
- **Lows** Controls the low end frequencies (pre fuzz)
- Bias (internal trim) Internal bias control

All trademarks and registered trademarks are the property of their respective owners. The company, product, and service names used in this web site are for identification purposes only. Use of these names, logos, and brands does not imply endorsement.



Marsh Fuzz

Parts List

RESISTORS			
R1	1M		
R2	68K1		
R3	1M		
R4	22K		
R5	47K		
R6	1K		
R7	10K		
R8	10K		
R10	100K		
R11	100K		
R13	100K		
R14	220R		
R16	12R4		
R17	1K		
R19	68K		
R20	1M		
R21	22K		
R22	47K		
R23	10K		
R24	1K		
R25	1K		
R26	100K		
R101	220R		
R102	220R		

R103 4K7

CAPAC	CITORS
C1	100p
C2	100n
C3	22u
C4	1n
C5	22u
C6	4n7
C7	22u
C10	100p
C12	220p
C14	22u
C15	22u
C16	22u
C18	100n
C20	3n3
C21	22u
C22	22u
C26	22u
C101	220u
C102	220u
C103	220u
C104	100n


TRAN	SISTORS	
01	BC549C	
Q2	BC549C	
Q3	BC549C	
Q4	BC549C	
DIODES		

D100 1N5817

POTENTIOMETERS		
VOLUME	A100K	
BIAS	B10K	
FUZZ	C1K	
HIGHS	A100K	
LOWS	A100K	

TRIM POTS	(3362P)
INT_BIAS	50K








Marsh Fuzz

Wiring Diagram





Marsh FuzzDrill Template
125B enclosure with top mounted jacks

