
Pixel Peeker user guide

Pixel Peeker is **a browser tool for designing LED video walls**: lay out cabinets on a canvas, add processors, wire the ports, and find out whether it actually fits — **before you find out on site.**

Runs entirely in the browser. No account, nothing uploaded.



An 8 m × 4.5 m wall: 144 cabinets, 3200×1800, 26.6 kW peak, serpentine-wired to 90% fill. The processor carries it on 11 of 20 ports at 64% device load — each colour on the canvas is one port.

> **Before you rely on this:** the capacity model is verified numerically — it reproduces NovaStar's three published MX40 Pro per-port figures **to the pixel** and Brompton's published per-port capacity table, and those are pinned as tests. The cabinet library was parsed from manufacturer datasheet PDFs, **each record carrying its source**.
>
> **It has not been used to design a wall that was then built.** No processor, receiving card, panel or distro has been connected to it, and the Resolume file has not been opened in a running Arena. The power circuits are steady-state arithmetic, checked against one published table. **Status: alpha**. The cabinet library covers the rental ranges of Absen, Aluvision, Gloshine, ROE Visual and Unilumin, and NovaStar and Brompton processing.
>
> This codebase was created with AI assistance, directed and reviewed by a human author.

The bit that matters: port capacity

Most LED capacity spreadsheets compute `pixels = link rate ÷ (3 × bit depth) ÷ frame rate`.

That is wrong at 10-bit, and wrong in the direction that gets you into trouble — it overstates capacity by about 7%.

Controllers pack each colour component into a **power-of-two container**, so the DMA engine stays word-aligned:

Bit depth	Naive (3 × depth)	Actual container
8-bit	24 bits/px	**24 bits/px**
10-bit	30 bits/px	**32 bits/px**
12-bit	36 bits/px	**48 bits/px**

With those containers, one link-efficiency figure reproduces the manufacturer's own published per-port numbers exactly — which is why the model is trusted rather than the arithmetic being plausible.

If a spreadsheet says a wall fits at 10-bit and this says it does not, this is the one to believe.

Laying out a wall

Pick a cabinet from the library, or define a custom panel by resolution and receiving card. Then fill a canvas, build blocks, or place tiles by hand.

- **New and dragged cabinets snap flush** against the ones already up.

- **Arrow keys extend a run** one cabinet at a time.
- **Shift locks a drag to 45°.**

Processing and wiring

NovaStar and Brompton controllers, with their real port counts, input connectors and **device capacity limits** — which are a separate limit from the sum of the ports, and the one that catches people.

Auto-wire in serpentine or column order to a chosen fill limit, or patch ports by hand.

Every port shows its **load, its headroom, and the highest frame rate it could sustain at that load** — that last figure being the one to check before promising 60 Hz on a 10-bit wall.

Power circuits

The **Power** section in the right sidebar takes a supply (230 V or 400 V three-phase in the UK/EU; 120, 208 or 240 V in the US), a breaker, and whether to **derate to 80%** for a continuous load. It gives **cabinets per circuit** and **circuits per cabinet model**, and the PDF report prints the same.

- **Always on peak power** — the all-white, full-brightness figure. A distro sized on average power trips on the first white holding slide.
- **Three phase is counted per leg**, at the phase voltage: a 400 V supply feeds the panels at 230 V.
- **Steady state only.** Inrush at switch-on is not modelled — it is why a wall is powered up in sections. **Sizing a circuit is a job for whoever signs off the distro.**

Line calc

Line calc in the top bar (or a link to `/#line`) is a quick calculator for one panel, without laying out a wall: **how many fit on one processor port, how many on one power circuit, and which of the two stops you.** The run you can build is the smaller, and it flips with the panel, the bit depth and the country.

- Pick a panel from the same library, or describe one by size, resolution and watts.
- Pick a processor, bit depth and frame rate for the **data line**; a supply, breaker and derate for the **power line**.
- The verdict says which line binds and how much of the other is left unused — spare power means the fix is another port, spare link capacity means it is another circuit.

- Enter a panel count for the whole-wall figures: ports, processors, circuits and total draw.

Where the manufacturer publishes a cabinets-per-cable figure (only Absen do, for the PL V2 range), it is shown alongside, with the margin they left. Line calc used to be a separate tool at line-calc.stoatworks-labs.com, which now redirects here.

What it checks

- Overlapping cabinets
- Unpatched tiles
- Over-capacity ports
- **A device that runs out before its ports do**
- An input too small to carry the wall
- Panels that cannot reach the wanted refresh rate
- **Chains that jump around the wall** — legal on paper, miserable in a truck

---

Exports

A **PDF report**, a **Resolume Advanced Output XML**, a **cabinet schedule CSV**, a **screen-configuration brief** for the processor vendors' own software, and a **versioned JSON interchange file**.

> **Use `Export → JSON` when handing a wall to another tool**, not *Save project*. The project file stores cabinets as library references in millimetres, which other tools cannot resolve to pixels.

If something looks wrong

Symptom	Cause
A wall that fits in my spreadsheet does not fit here	10-bit container padding. See above — the spreadsheet is the one that is wrong.
The device is full but the ports are not	Device capacity is a separate limit from the sum of the ports.
A port cannot reach 60 Hz	Read the max-frame-rate column for that port's load.
Another tool refuses my export	It needs the JSON export, not the project save.
Line calc allows more panels per circuit than Absen publish	Absen's table is a conservative recommendation for their cable inside 16 A; Line calc works to your breaker. The gap is shown.
"Max. hanging" on a ROE sheet does not match the circuit count	It is a mechanical limit, not a power one.
A cabinet's spec looks wrong	Each record carries its datasheet source — check it there. Series-wide facts are in the comment above the series in `src/data/cabinets/`.