## Req580.BeginFirmwareUpdate.uavcan

+uint8 source\_node\_id +Path image\_file\_remote\_path

## Resp580.BeginFirmwareUpdate.uavcan

+uint8 ERROR\_OK = 0

+uint8 ERROR\_INVALID\_MODE = 1

+uint8 ERROR\_IN\_PROGRESS = 2

+uint8 ERROR\_UNKNOWN = 255

+uint8 error = [BootLoadInProcess] ? ERROR\_IN\_PROGRESS : ERROR\_OK

+int4 STATUS\_INITIALIZING = 1

+int4 STATUS WARNING = 2

+int4 STATUS\_CRITICAL = 3 +int4 STATUS\_OFFLINE = 15

+int4 status\_code

+int16 vendor\_specific\_status\_code

Page 1 of 2







