

Dishwasher Repair Guide

Safety First

Disconnect power and shut off water before servicing.

Common Problems

1. Won't start: Check breaker, door latch, and power supply.
2. Not draining: Clean filter, inspect drain hose, and pump.
3. Poor cleaning: Clean spray arms, load correctly, use fresh detergent.
4. Leaking: Inspect door gasket, inlet valve, and hose connections.
5. Strange noise: Remove debris, inspect spray arms and circulation pump.

Basic Maintenance

Clean the filter monthly, run a cleaning cycle with dishwasher cleaner, inspect hoses yearly, and avoid overloading.

When to Call a Professional

Burning smell, electrical issues, motor failure, major leaks, or control board faults.