


Operators Manual

CRAFTSMAN®

2 TON CAPACITY FLOOR JACK

Model No. 50239



CAUTION:

Before using this product, read this manual and follow all its Safety Rules and Operating instructions.

- Safety
- Assembly
- Operation
- Maintenance
- Parts

Complies with ANSI standards for automotive lifting devices

Sears, Roebuck and Co., Hoffman Estates, IL 60179
Visit our Craftsman website: www.sears.com/craftsman
US Patents: 5,755,099 5,937,647 6,199,379B1

Part No. 6207

50239-OM

Printed in China

TABLE OF CONTENTS

Warranty	P. 2
Save these instructions	P. 2
Safety instructions	P. 3
Assembly	P. 3
Operation	P. 4
Maintenance	P. 5
Troubleshooting	P. 6
Parts	P. 6
Service	Back page

WARRANTY

One Year Full Warranty on Craftsman Floor Jack

If within one year from date of purchase, this Craftsman floor jack fails due to a defect in material or workmanship, return it to the nearest Sears store in United States and Sears will replace it, free of charge.

If this floor jack is used for commercial or rental purposes, this warranty will apply for only 30 days from date of purchase.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Sears Roebuck and Co., Dept. 817WA, Hoffman Estates, IL 60179

SAVE THESE INSTRUCTIONS

For your safety, read, understand, and follow the information provided with and on this jack.

- The owner and operator of this equipment shall have an understanding of this jack and safe operating procedures before attempting to use. The owner and operator shall be aware that use and repair of this product may require special skills and knowledge. Instructions and safety information shall be conveyed in the operator's native language before use of this jack is authorized. If any doubt exists as to the safe and proper use of this jack, remove from service immediately.
- Inspect before each use. Do not use if broken, bent, cracked, or damaged parts (including labels) are noted. Any jack that appears damaged in any way, operates abnormally or is missing parts, shall be removed from service immediately.
- If the jack has been or suspected to have been subjected to a shock load (a load dropped suddenly, unexpectedly upon it), immediately discontinue use until jack has been checked by a factory authorized service center. It is recommended that an annual inspection be done by qualified personnel.
- Labels and Owner's Manuals are available from manufacturer (see PARTS section on page 6).

SAFETY INSTRUCTIONS

WARNING

- Study, understand, and follow all instructions with and on this device before operating this device.
- Do not exceed rated capacity.
- Use only on hard, level surfaces capable of sustaining rated capacity loads.
- Lift only on areas of the vehicle as specified by the vehicle manufacturer.
- This is a lifting device only. Immediately after lifting, support the vehicle with appropriately rated vehicle stands.
- Never work on, under, or around a load supported only by this device.
- Do not move or dolly the vehicle while on the jack.
- No alterations shall be made to this product.
- Failure to heed product markings or warnings may result in personal injury or property damage.

CAUTION BEFORE USING

Occasionally during shipment and/or handling the hydraulic oil can become unstable or air can get trapped in the system, both of which can interfere with the jacks lifting performance.

- To stabilize the oil it is recommended to cycle the jack a few times prior to putting a load on it.
- To release air from the hydraulic system:
 - Open the release valve by turning the jack handle counterclockwise, but never by more than 1/2 full turns.
 - Remove the air vent valve from the cylinder. (see Fig. 4)
 - Rapidly pump jack handle through several full strokes.
 - Replace the air vent valve into the cylinder again and jack is now ready to use.

BEFORE EACH USE

Make a visual inspection before each use of the floor jack by checking for abnormal conditions, such as cracked welds, leaks and damaged, loose, or missing parts.

DAMAGE TO JACK

If you think jack has been subjected to an abnormal load or shock, have it inspected for damage at a Sears Service Center before using it again.

ASSEMBLY

TO ASSEMBLE THE TWO PIECE HANDLE

1. Locate the Spring Pin on bottom end of Upper Handle and the Fixing Hole on the top end of Lower Handle. (See Fig. 1)
2. Align the Spring Pin with the Fixing Hole. Connect the two handle pieces together by pressing the Spring Pin and insert until the Spring Pin is locked in the Fixing Hole.




FIG. 1

TO ASSEMBLE THE HANDLE INTO THE SOCKET

1. Pull out and hold the Spring Knob (see Fig. 2)
2. Insert the assembled handle into the Socket, until it is firmly seated.
3. Release the Spring Knob, the handle is then fixed in position.




FIG. 2

OPERATION

KNOW YOUR JACK

Compare Fig. 3 illustration with your jack BEFORE operation to become familiar with the location of various jack components.




FIG. 3

OPERATING PRINCIPLES

- With release valve closed, an upward stroke of the jack handle draws oil from the reservoir tank into the plunger cavity. Hydraulic pressure holds the valve closed, which keeps the oil in the plunger cavity.
- A downward stroke of the jack handle releases oil into the cylinder, which forces the ram out. This raises the saddle. (NOTE: To avoid damage to the

cylinder if the load exceeds the rated capacity of the jack, oil is automatically released back into the reservoir through the safety overload valve.)

- When the ram reaches maximum extension, oil is bypassed back into the reservoir to prevent an over-extended ram stroke and possible damage to the jack.
- Opening the release valve allows oil to flow back into the reservoir. This releases hydraulic pressure on the ram, which results in lowering the saddle.

HOW TO USE YOUR JACK

RAISING THE JACK

- Chock the vehicle wheels with appropriate devices to prevent vehicle from moving and to ensure lifting stability.
- Close the release valve by turning the jack handle clockwise until tight. (see Fig. 3)
- Refer to the vehicle manufacturer's owner's manual to locate approved lifting points on the vehicle. Position jack so that the saddle (see Fig. 3) is centered under the load at an appropriate lift point.
- Pump jack handle until saddle ALMOST contacts the vehicle. Check to see that the saddle is centered and will contact the load lifting point firmly.
- Continue to pump the jack handle to lift the vehicle to the desired height. After lifting, support the load with appropriately rated vehicle support stands BEFORE working on the vehicle.

LOWERING THE JACK

- SLOWLY open the release valve by turning the handle counterclockwise. Never more than 1/2 turns.

CAUTION: Keep hands and feet clear of the jack hinge mechanism and ground contact area when lowering the load!

SPECIFICATIONS

Rated Capacity: 2 Ton/4000 Lb

Jack Dimensions: 27-3/4" x 12-1/8" x 6-1/4"

Lifting Range: 3-3/4" ~ 18-1/2" (Approx.)

Oil Capacity: 150 c.c.

Net Weight: 42.5 lbs. (Approx.)

MAINTENANCE

MAINTAINING OIL LEVEL

Important: When adding or replacing oil, ALWAYS use a good grade Hydraulic Jack oil. DO NOT use Hydraulic Brake Fluid, Alcohol, Glycerine, Detergent, Motor Oil or dirty oil. Use of an improper fluid can cause serious internal damage to your jack. We recommend Mobil DTE13M or equivalent.

ADDING OIL

- Position the jack on level ground and fully lower the saddle. (Ram will be all the way in). Remove air vent valve located under tool tray (see Fig. 3 & 4).
- Oil should be filled to the level of about 3/16" above the inner cylinder as seen from the oil filler hole. If low, add oil as needed.
- Re-install air vent valve and tool tray. The jack is now ready to use.

LUBRICATION

- Add lubricating oil to all moving parts as needed.

PREVENTING RUST

- Check ram and pump plunger (see Fig. 4) every few months for any signs of rust or corrosion. Clean as needed by wiping with an oily cloth.

- When not in use, ALWAYS store jack with saddle and pump plunger lowered all the way down.

ANNUAL INSPECTION

To ensure that it is in optimum condition, annual inspection of the jack at a Sears Service Center is recommended.

REPLACING OIL

- To drain oil, remove tool tray and air vent valve and open release valve. Turn jack over and drain old oil out through the oil filler hole.
- Refill with new oil through the oil filler hole. DO NOT allow dirt or other foreign material to enter the hydraulic system when filling.
- After refilling, remove any air from the hydraulic system by opening the release valve and rapidly pumping the jack handle several times.
- Re-install air vent valve and tool tray and the jack is ready to use.




FIG. 4

TROUBLESHOOTING

PROBLEM-SOLVING HINTS

Symptom	Possible Causes	Corrective Action
Jack will not lift load	- Release valve not tightly closed - Overloaded - too much weight on jack	- Ensure release valve is tightly closed - Reduce weight on jack
Jack bleeds off (starts to lower) after lift	- Release valve not tightly closed - Too much weight on jack - Hydraulic unit malfunction	- Ensure release valve is tightly closed - Reduce weight on jack - Replace Power Unit Assembly
Jack will not lower after unloading	- Oil reservoir overfilled - Linkages binding	- Drain fluid to proper level - Clean and lubricate moving parts
Poor lift performance	- Fluid level low - Air trapped in system	- Ensure proper fluid level - With ram fully retracted, open release valve, pump handle several times to expel trapped air
Will not lift to full extension	Fluid level low	Ensure proper fluid level

PARTS

MODEL NUMBER: 50239

The Model Number and Serial Number are found on the lifting arm and handle socket respectively. Always mention the Model Number and Serial Number when requesting service or repair parts for your jack.

PARTS ARE ONLY AVAILABLE IN ASSEMBLIES (except Saddle)

Key	Parts NO.	Description
1	6201	Saddle
2	6202	Power unit assembly
3	6203	Handle Assembly
4	6204	Front Roller Assembly
5	6205	Handle Socket
6	6206	Rear Castor Assembly
—	6207	Operators manual




FIG. 5

Your Home

For repair – **in your home** – of **all** major brand appliances,
lawn and garden equipment, or heating and cooling systems,
no matter who made it, no matter who sold it!

For the replacement parts, accessories and
owner's manuals that you need to do-it-yourself.

For Sears professional installation of home appliances
and items like garage door openers and water heaters.

1-800-4-MY-HOME® (1-800-469-4663)

Call anytime, day or night (U.S.A. and Canada)

www.sears.com www.sears.ca

Our Home

For repair of carry-in items like vacuums, lawn equipment,
and electronics, call or go on-line for the location of your nearest
Sears Parts and Repair Center.

1-800-488-1222

Call anytime, day or night (U.S.A. only)

www.sears.com

To purchase a protection agreement (U.S.A.)
or maintenance agreement (Canada) on a product serviced by Sears:

1-800-827-6665 (U.S.A.)

1-800-361-6665 (Canada)

Para pedir servicio de reparación
a domicilio, y para ordenar piezas:

1-888-SU-HOGARSM
(1-888-784-6427)

Au Canada pour service en français:

1-800-LE-FOYER^{MC}
(1-800-533-6937)
www.sears.ca

SEARS

®Registered Trademark / TMTrademark / SMService Mark of Sears, Roebuck and Co.

®Marca Registrada / TMMarca de Fabrica / SMMarca de Service de Sears, Roebuck and Co.

^{MD}Marque de déposée / ^{MC}Marque déposée de Sears, Roebuck and Co.

© Sears, Roebuck and Co.