

Owner's Manual and Operating Instructions for Pressure Regulated Double Burner Propane Lantern



CAUTION: Read all Warnings and Operating Instructions before use and retain for future reference.

Model #170-900

runtime 4.2 hour
with 16.4 oz propane
810 Lumens



Recommended Replacement Parts

Part Number	Description
167	Globe
166	Mantles

FOR YOUR SAFETY

Do not store or use gasoline or other liquids with flammable vapors in the vicinity of this or any other appliance.

⚠ WARNING

FIRE OR EXPLOSION HAZARD


If you smell gas:

1. Do not attempt to light appliance.
2. Extinguish any open flame.
3. Disconnect from fuel supply.
4. Evacuate immediately
5. Allow gas to dissipate 5 minutes before relighting the appliance

Failure to follow these instructions could result in fire or explosion, which could cause property damage, personal injury, or death

⚠ WARNING

- FOR OUTDOOR USE ONLY.
- Supply plenty of fresh air when using the lantern. Do not obstruct the flow of combustion air or ventilation air.
- Do not use as a space heater.
- Lanterns produce heat. Keep lantern away from combustible materials.
- Do not place the lantern any closer than 32" to combustibles.
- Use a flat, level support surface where the lantern is safe from accidental tipping.
- Use only 16.4 oz. propane cylinders marked per USDOT-39 or TC CAN/CSA B339 standards.
- Use only with propane fuel
- Use only the 16 psi regulator included with your lantern. Do not attempt to alter.

ITEM	PART	QTY (PCS)	PART NAME
A		1	HANDLE
B		1	NUT
C		1	LID
D		1	BRACKET
E		2	MANTLES
F		1	GLOBE WITH REGULATOR
G		1	"DURA-BASE"

⚠ DANGER



CARBON MONOXIDE HAZARD

This appliance can produce carbon monoxide which has no odor.

Using it in an enclosed space can kill you.

Never use this appliance in an enclosed space such as a camper, tent, car or home.

CAUTION

Propane fuel is highly flammable and under pressure.

- Do not store in temperatures over 120°F.
- Never use a flame to check for leaks. Use soapy water.
- Keep out of the reach of children at all times.
- Keep cylinders upright with cylinder base equipped for proper vapor withdrawal.
- The smell of gas indicates a leak. Close valves and check for leaks by brushing soapy water on all joints. There is a leak if bubbles appear. Tighten the joint until the bubbles quit.
- Always check all connections for dirt or damage before assembling.
- Do not leave lantern unattended while in use.
- Do not connect to a remote gas supply!
- If lantern is stored indoors, detach and leave the cylinder outdoors.

1 PREPARING THE LANTERN FOR USE

1. Make sure the regulator is in the "—" OFF position.
2. Screw lantern onto propane cylinder. Take care not to cross thread. Hand tighten only.
3. Firmly seat the propane cylinder into the cylinder base after extending base feet.
4. Place on a flat even, level surface.

2 INSTALLING MANTLES

CAUTION: Replace any mantle that has a hole in it. Holes can cause lantern glass globe to overheat or crack. Always have a spare set of mantles. Once burned, mantle becomes fragile and can be damaged if touched or dropped.

1. Remove the lantern dome, globe, and cardboard packaging
2. Tie mantles around groove of lantern burners. **Trim excessive string after tightening mantle onto lantern burners, excessive string could damage mantles and cause glass globe breakage and other lantern malfunctioning.**
3. Spread mantle fabric as evenly and smoothly as possible
4. Using a match or lighter, ignite the mantles. You may turn the lantern on to the LOWEST setting (by turning valve counter-clockwise) to help speed the burning of mantle fabric. Shelter the mantles from the wind as they are burning. After the mantle is burned off completely, light the mantle with control valve turned full on - this will allow the mantle to form around the mantle tube (takes only about 3-5 seconds). Turn lantern off and allow to cool.

After priming / pre-burning mantles, be cautious to protect them from impact, not to damage or create holes. Replace mantle if there's hole.

5. Replace the globe. Be careful not to touch the mantles. Do not overtighten lantern dome onto glass globe. Always allow minor room for globe glass expansion after it is heated.

CAUTION:

- Avoid carry mantles close to the body whether in packages or not, for extended periods of handling mantles more than necessary. Wash hands after handling.
- Avoid breathing vapors or ash from mantle.
- Keep mantle and ash out of the reach of children: Harmful if swallowed.
- Avoid skin contact with ash and dispose of carefully.
- Wash hands after handling ash.
- Keep ash away from food.

3 OPERATING INSTRUCTIONS

WARNING: DO NOT put hands or other body parts over the lantern during lighting or when in use to prevent burns.

FOR YOUR SAFETY: DO NOT store or use gasoline or other flammable vapors, liquids or chemicals in the vicinity of this or any other appliance during lighting or operation.

- Using a match or lighter, hold a flame to the lighting hole in the burner assembly base, turn on the fuel by turning valve counter-clockwise until lantern mantle light.
- Mantle should burn brightly with no external flame

Never operate lantern with a hole or crack in the mantle. Do not operate the lantern with no mantles.



STORING THE LANTERN

CAUTION: The globe and lantern lid are VERY HOT after shutting off the lantern.

1. Before storing, allow the lantern 15 minutes to cool
2. Detach cylinder.
3. Store in carrying case or in a clean dry place.
4. DO NOT store propane cylinder indoors.

CLEANING

1. Allow the lantern to cool completely.
2. Carefully remove the propane cylinder by grasping the lantern and rotating the cylinder in a counter-clockwise direction.
3. Unscrew the lantern lid nut.
4. Carefully pull outward on the metal bail and remove from the burner assembly.
5. Lift the metal lantern lid off the center burner assembly post.
6. Remove the glass globe and clean with a soft cloth.
7. Remove the used mantles and replace with new ones.
8. Replace the glass globe and lantern lid. Be sure to align the holes in the lantern lid with holes on the inner burner assembly.
9. Replace the metal bail handle into the lantern lid holes.
10. Reinstall and tighten the lantern lid nut. Hand tighten only. Always allow minor room for globe glass expansion after it is heated.

SERVICE AND REPAIR

1. Clean your lantern after each use and before storage.
2. Replacement glass globes and mantles can be purchased at your local camping dealer.
3. No other parts are serviceable in the field. If your lantern requires additional service, please contact customer service at: 800-421-6131.

STANDARD SALES, INC
2801 East 12th St. • Los Angeles, CA 90023
Toll Free 1-800-421-6131

MADE IN CHINA