

2025 translucent thermometer

User Manual for capetsma Aquarium Thermometer



Specification:

1. Measuring Range: 0°C - 70°C (32°F- 158°F).
2. Precision: ± 1 degree.
3. Measurement cycle: 30s/time.
4. Initial temperature range: 20°C - 30°C.
5. Press any diamond key to change °C to °F
6. Digital display, Large screen, narrow frame.
7. Wide application: Fit for fresh water and salt water fish tank.
8. Size: 75*77*10mm.
9. Battery: 3V CR2032*1.

Brand:
Apetsma

Flashing Warning when higher than highest.

or Lower than Lowest.

Current Temp

Set High Temp Warning
Low Temp Warning



Big number displays current temperature.

First Small number means HIGHEST temperature you want it to warning.
Second small number means LOWEST temperature you want it to warning.
Pls make "Hi xx F > current temp > Lo xx F", it will stop flashing.



C / F Switch by

How to change Fahrenheit to Celsius ?

Press "up" or "down" diamond key to switch between C / F

How to replace battery ?



1. Pull down the battery cover.



2. Take down the battery and install a new battery.



3. Find the matching connection between the battery cover and the thermometer then slanting insert, then press down.



4. Push upward the battery cover.

Trouble shooting:

It keeps flashing, how to stop ?

It is not defective, it is showing that the current temperature is too high or too low, if you want to stop it, pls make "Hi xx F > current temp > Lo xx F", it will stop flashing.

How to set the "Hi xx F" and the "Lo xx F" ?

press the "set" key, the first small number will flash, short press "up" or "down" to set up the highest temperature you want it to flash, then press "set", the other small number will flash, short press "up" or "down" key to set up the lowest temperature. Done.

Notice: If you replace the battery, this thermometer will be back to Celsius and default high / low temperature flash point is 30 C / 20 C,

The thermometer goes blank, what to do ?

Change the battery, it will be ok.

The temperature displays incomplete. Is that ok ?

If it falls down then displays incomplete, It means that the thermometer is defective. You need a new one.

We offer 180 days warrantee, if you have any problem, pls contact us, we will reply in 24hrs and will do our best to help.