

Duck



Drops output volume while the Duck button is held. Use it to avoid shouting over loud music and to see if dancers stay on the beat when the music disappears.

Configurable volume level for the Duck is in Settings.

