

## W48 - ErdTone - Quick Reference

DR: Dial & Release  
H1: Hold -> 1st beep  
H2: Hold -> 2nd beep

### Normal dialing (DR)

DR: 0-9 DTMF tone sent

Pause >3 s Stores a pause in redial

### Earth key (Erdtaste)

Short press Redial last number

H1 Dial Earth key slot

H2 Program Earth key slot

Press at pickup Cancel auto-dial for this session

### H1 actions

H1: 1 Send \*

H1: 2 Send #

H1: 3 Redial last number

H1: 4-9,0 Dial speed-dial slot

## Programming (H2 to enter)

### H2 actions

H2: 4-9,0 Enter slot programming

H2: 1 Toggle DTMF 80/200 ms

H2: 2 Toggle hold 1/2 s

H2: 3 Enter auto-dial setup

### During slot programming

DR: 0-9 Store digit

H1: 1 or 2 Store \* or #

H1: 3 Store pause

H1: 4-9,0 Copy speed-dial slot

Earth key Copy last dialed

H2: 0 Clear this slot

Hang up Save & exit

### During auto-dial setup

1. Select # Earth key slot or speed-dial slot 4-9, 0

2. Set delay Dial 0-9 seconds

H2: 0 Clear auto-dial

## Service codes (\* # via H1)

### Set lock (no PIN set)

\*\*PIN Lock programming

\*#PIN Lock programming and dialing

PIN 3 digits from 0-9

### Unlock (\* # via H1)

\*\*PIN Permanent unlock

##PIN Unlock for this call only

### Fully locked mode

DR: 4-9,0 Dial speed-dial

DR: Earth key Dial Earth key slot

DR: 1,2,3 No action

### Factory reset

\*#0#\* Erase all (blocked if locked)

