

W48 - ErdTone - Quick Reference	Programming (H2 to enter)	Service codes (* # via H1)
<i>DR: Dial & Release</i> <i>H1: Hold -> 1st beep</i> <i>H2: Hold -> 2nd beep</i>	H2 actions	Set lock (no PIN set)
Normal dialing (DR)	H2: 4-9,0 Enter slot programming H2: 1 Toggle DTMF 100/200 ms H2: 2 Toggle hold 1/2 s H2: 3 Enter auto-dial setup	**PIN Lock programming *#PIN Lock programming and dialing
DR: 0-9 DTMF tone sent		PIN 3 digits from 0-9
Pause >3 s Stores a pause in redial	During slot programming	Unlock (* # via H1)
Earth key (Erdtaste)	DR: 0-9 Store digit H1: 1 or 2 Store * or # H1: 3 Store pause H1: 4-9,0 Copy speed-dial slot Earth key Copy last dialed H2: 0 Clear this slot Hang up Save & exit	**PIN Permanent unlock ##PIN Unlock for this call only
Short press Redial last number	During auto-dial setup	Fully locked mode
H1 Dial Earth key slot	1. Select # Earth key slot or speed-dial slot 4-9, 0 2. Set delay Dial 0-9 seconds H2: 0 Clear auto-dial	DR: 4-9,0 Dial speed-dial DR: Earth key Dial Earth key slot DR: 1,2,3 No action
H2 Program Earth key slot		Factory reset
Press at pickup Cancel auto-dial for this session		*#0#* Erase all (blocked if locked)
H1 actions		
H1: 1 Send * H1: 2 Send # H1: 3 Redial last number H1: 4-9,0 Dial speed-dial slot		

W48 - ErdTone - Quick Reference	Programming (H2 to enter)	Service codes (* # via H1)
<i>DR: Dial & Release</i> <i>H1: Hold -> 1st beep</i> <i>H2: Hold -> 2nd beep</i>	H2 actions	Set lock (no PIN set)
Normal dialing (DR)	H2: 4-9,0 Enter slot programming H2: 1 Toggle DTMF 80/200 ms H2: 2 Toggle hold 1/2 s H2: 3 Enter auto-dial setup	**PIN Lock programming *#PIN Lock programming and dialing
DR: 0-9 DTMF tone sent	During slot programming	PIN 3 digits from 0-9
Pause >3 s Stores a pause in redial	DR: 0-9 Store digit H1: 1 or 2 Store * or # H1: 3 Store pause H1: 4-9,0 Copy speed-dial slot Earth key Copy last dialed H2: 0 Clear this slot Hang up Save & exit	Unlock (* # via H1)
Earth key (Erdtaste)	During auto-dial setup	**PIN Permanent unlock ##PIN Unlock for this call only
Short press Redial last number	1. Select # Earth key slot or speed-dial slot 4-9, 0 2. Set delay Dial 0-9 seconds H2: 0 Clear auto-dial	Fully locked mode
H1 Dial Earth key slot		DR: 4-9,0 Dial speed-dial DR: Earth key Dial Earth key slot DR: 1,2,3 No action
H2 Program Earth key slot		Factory reset
Press at pickup Cancel auto-dial for this session		*#0#* Erase all (blocked if locked)
H1 actions		
H1: 1 Send * H1: 2 Send # H1: 3 Redial last number H1: 4-9,0 Dial speed-dial slot		