

W48 - ErdTone - Quick Reference

DR: Dial & Release
H1: Hold -> 1st beep
H2: Hold -> 2nd beep

Normal dialing (DR)

DR: 0-9 DTMF tone sent

Pause >3 s Stores a pause in redial

Earth key (Erdtaste)

Short press Redial last number

H1 Dial Earth key slot

H2 Program Earth key slot

Press at pickup Cancel auto-dial for this session

H1 actions

H1: 1 Send *

H1: 2 Send #

H1: 3 Redial last number

H1: 4-9,0 Dial speed-dial slot

Programming (H2 to enter)

H2 actions

H2: 4-9,0 Enter slot programming

H2: 1 Toggle DTMF 100/200 ms

H2: 2 Toggle hold 1/2 s

H2: 3 Enter auto-dial setup

During slot programming

DR: 0-9 Store digit

H1: 1 or 2 Store * or #

H1: 3 Store pause

H1: 4-9,0 Copy speed-dial slot

Earth key Copy last dialed

H2: 0 Clear this slot

Hang up Save & exit

During auto-dial setup

1. Select # Earth key slot or speed-dial slot 4-9, 0

2. Set delay Dial 0-9 seconds

H2: 0 Clear auto-dial

Service codes (* # via H1)

Set lock (no PIN set)

****PIN** Lock programming

***#PIN** Lock programming and dialing

PIN 3 digits from 0-9

Unlock (* # via H1)

****PIN** Permanent unlock

##PIN Unlock for this call only

Fully locked mode

DR: 4-9,0 Dial speed-dial

DR: Earth key Dial Earth key slot

DR: 1,2,3 No action

Factory reset

#0# Erase all (blocked if locked)



W48 - ErdTone - Quick Reference

DR: Dial & Release
H1: Hold -> 1st beep
H2: Hold -> 2nd beep

Normal dialing (DR)

DR: 0-9 DTMF tone sent

Pause >3 s Stores a pause in redial

Earth key (Erdtaste)

Short press Redial last number

H1 Dial Earth key slot

H2 Program Earth key slot

Press at pickup Cancel auto-dial for this session

H1 actions

H1: 1 Send *

H1: 2 Send #

H1: 3 Redial last number

H1: 4-9,0 Dial speed-dial slot

Programming (H2 to enter)

H2 actions

H2: 4-9,0 Enter slot programming

H2: 1 Toggle DTMF 100/200 ms

H2: 2 Toggle hold 1/2 s

H2: 3 Enter auto-dial setup

During slot programming

DR: 0-9 Store digit

H1: 1 or 2 Store * or #

H1: 3 Store pause

H1: 4-9,0 Copy speed-dial slot

Earth key Copy last dialed

H2: 0 Clear this slot

Hang up Save & exit

During auto-dial setup

1. Select # Earth key slot or speed-dial slot 4-9, 0

2. Set delay Dial 0-9 seconds

H2: 0 Clear auto-dial

Service codes (* # via H1)

Set lock (no PIN set)

****PIN** Lock programming

***#PIN** Lock programming and dialing

PIN 3 digits from 0-9

Unlock (* # via H1)

****PIN** Permanent unlock

##PIN Unlock for this call only

Fully locked mode

DR: 4-9,0 Dial speed-dial

DR: Earth key Dial Earth key slot

DR: 1,2,3 No action

Factory reset

#0# Erase all (blocked if locked)

