

Aurora Brew 3000 - User Manual (Part 3: Maintenance & Troubleshooting)

1. Daily cleaning

- Empty the used coffee grounds and rinse the filter basket.
- Wash the carafe and lid with warm soapy water after each use.
- Wipe the warming plate with a damp cloth once the machine is cool.

2. Descaling

Descale the machine every 60 brews or every 3 months, whichever comes first.

1. Fill the reservoir with a mixture of one part white vinegar and two parts water.
2. Place a carafe in position and run a full brew cycle without coffee.
3. Discard the liquid and run two more cycles with clean water.

3. Water filter replacement

Replace the built-in carbon filter every 90 days or every 100 brews.

The filter indicator light on the control panel will flash when a replacement is due.

4. Troubleshooting

Problem: Machine does not turn on.

Cause: No power, or the power cord is not fully seated.

Fix: Check the outlet and the cord connection. Reset the circuit breaker.

Problem: Coffee is too weak.

Cause: Not enough coffee grounds, or the brew-strength selector is set to Mild.

Fix: Increase the amount of coffee or select the Strong brew setting.

Problem: Brewing is slow.

Cause: The machine needs descaling.

Fix: Run the descaling procedure described above.

Problem: Coffee tastes bitter.

Cause: The carafe was left on the warming plate for more than 2 hours.

Fix: Use the pause-and-serve function and do not reheat coffee.

5. Technical support

Contact Aurora customer care at support@aurorabrew.example or call +1-800-555-AURORA.

Have your serial number ready. The serial number is located on the underside.