

ATM PROCEDURES : STOP, START, REBOOT & SHUTDOWN A NODE.

FROM THE TECHNICAL POSITION (RCMS), click on icon MAER to see all operational nodes (green status)

Procedure to stop a node:

Left click and open a unix-window (xterm)

1. Check if the node is responding to the network by typing the following command:

> ping (a node for e.g maerplc03sv)

> ping maerplc03sv

Check for lost packet, 0 % packet loss.

To stop the ping process press:

Ctrl+C

2. Remote login the node by typing: (for e.g maerplc03sv)

> rsh maerplc03sv (press ENTER)

OR

Go to Display and select maerplc03sv

Check for the inter process by typing

> ipcs

3. stop the node by typing:

> stop node (Note: You will get 3 lines of data)

Check for the inter process by typing again:

> ipcs

4. Start the node again by typing:

> start node (wait for normalization, node will be green on RCMS)

> ipcs - (You will get a long list of data).

Procedure to reboot a node:

To stop the node and reboot the node:

Carry out procedures 2 & 3 to stop the node.

How to reboot the node?

Login as a super user by typing:

su -

Enter password: abc123

shutdown -r now - Note: You will get a black screen, you will have to start the node by typing:

Note: To shutdown a node completely type:

> start node.

> #shutdown -h now

to switch on the node again, press the physically Power ON button on the Workstation.

= Note: You will get a black screen, you will have to start the node by typing:

> start node

ATM PROCEDURES : STOP START REBOOT SHUTDOWN A NODE.

FROM THE TECHNICAL POSITION:

Procedure to stop a node:

Left click and open unix-window (xterm)

1. Check if the the node is responding to the network by typing the following command:

> ping (the hostname)

Check for lost packet

To stop the process press:

Ctrl+C

2. Remote login the node by typing:

> rsh (hostname)

Check for the inter process by typing:

> ipcs

3. stop the node by typing:

> stop node

Check for the inter process by typing again:

> ipcs

4. Start the node again by typing:

> start node

OR Go to "Display" on RcMS
and select the node
required:

Procedure to reboot a node:

If the node is still in degradation mode, then stop the node and reboot the node:

Carry out procedures 2 & 3 to stop the node.

How to reboot the node?

Login as a super user by typing:

su -

Enter password: abc123

shutdown -r now

Note to halt/shutdown a node completely type:

> #shutdown -h now

to switch on the node again, press the physically Power ON button.

Received on 27 Sep 2021
80 Randhaz

ATM PROCEDURES

FROM THE TECHNICAL POSITION:

- **Procedure to stop a node:**

Left click and open unix-window (xterm)

1. Check if the the node is responding to the network by typing the following command:
> ping (the hostname)
Check for lost packet
To stop the process press:
Ctrl+c
2. Remote login the node by typing:
> rsh (hostname)
Check for the inter process by typing:
> ipcs
3. stop the node by typing:
> stop node
Check for the inter process by typing again:
> ipcs
4. Start the node again by typing:
> start node

- **Procedure to reboot a node:**

If the node is still in degradation mode, then stop the node and reboot the node:

Carry out procedures 2 & 3 to stop the node.

- **How to reboot the node?**

Login as a super user by typing:

> su -

Enter password: abc123

#shutdown -r now

- **Note to halt the node completely type:**

> #shutdown -h now

to switch on the node again, press the Power ON button.