

[illegible]

NC pins are intentionally unused. SWD probe connects on the module top.

FROM 5V IN

+5V_MOTION

1

2

GND

C8
10u

GND

+5V2

R8
10k

USER_KEY_N

1

2

GND

J6
ER BUTTON

#FLC2
Supply boundary

GND

#FLC3
Supply boundary

+5V3

+5V_MOTION

-5V_MOTION

H1
M2 clearance

H2
M2 clearance

H3
M2 clearance

al display is, R8 reset can cause a fail

J6 is a user button. Physical disable is J8; reset can cause a fall.

[illegible]

3.3 V logic; actuator thresholds and timing remain bench items.

CLR_N dominates. Re-arm requires a new ARM_CLK edge; this is not a watchdog

CAN_3V3 powers translator B only. It does not power the motion MCU.

3.3 V logic; actuator thresholds and timing remain bench items

U3
5K74LVCC2520CUIR

3V3

R3
10k

R4
10k

S2B8_OE_N

HEAD_OE_N

1A
1B
2A
2B
1Y
2Y
1Q
2Q

GND

OE_N = request_N OR ARM_Q_N. Pull-ups disable TX by default.

Pin configuration diagram for the J4 header of the IMU module. The diagram shows a vertical green line representing the signal path, with a red box indicating the connection point for the +3V5 supply. The J4 header is a 10-pin connector with pins labeled 1 through 10. The connections are:

- Pin 1: +3V5
- Pin 2: GND
- Pin 3: IMU_SCK
- Pin 4: IMU_MOSI
- Pin 5: IMU_MISO
- Pin 6: IMU_CS
- Pin 7: IMU_DRDY
- Pin 8: GND
- Pins 9 and 10: J4 BODY IMU SPI

SPI and DRDY belong to the rigid body IMU, not the head.

1k / 10nF filters at the ADC inputs. Scaling is on the power board