* Chipselect/Local Bus

};

```
Properties:
- name : Should be localbus
- #address-cells : Should be either two or three. The first cell is the
                     chipselect number, and the remaining cells are the
                     offset into the chipselect.
- #size-cells: Either one or two, depending on how large each chipselect
                  can be.
- ranges: Each range corresponds to a single chipselect, and cover
            the entire access window as configured.
Example:
         localbus@f0010100 {
                  \#address-cells = \langle 2 \rangle;
                  \#size-cells = \langle 1 \rangle:
                  reg = \langle f0010100 \ 40 \rangle;
                  ranges = <0.0 fe000000 02000000
                             1 0 f4500000 00008000>;
                  flash@0, 0 {
                           compatible = "jedec-flash";
                           reg = \langle 0 \ 0 \ 20000000 \rangle;
                           bank-width = \langle 4 \rangle;
                           device-width = \langle 1 \rangle;
                  };
                  board-control@1, 0 {
                           reg = \langle 1 \ 0 \ 20 \rangle;
                           compatible = "fs1, mpc8272ads-bcsr";
                  };
```