eisa. txt

EISA bus support (Marc Zyngier <maz@wild-wind.fr.eu.org>)

This document groups random notes about porting EISA drivers to the new EISA/sysfs API.

Starting from version 2.5.59, the EISA bus is almost given the same status as other much more mainstream busses such as PCI or USB. This has been possible through sysfs, which defines a nice enough set of abstractions to manage busses, devices and drivers.

Although the new API is quite simple to use, converting existing drivers to the new infrastructure is not an easy task (mostly because detection code is generally also used to probe ISA cards). Moreover, most EISA drivers are among the oldest Linux drivers so, as you can imagine, some dust has settled here over the years.

The EISA infrastructure is made up of three parts:

- The bus code implements most of the generic code. It is shared among all the architectures that the EISA code runs on. It implements bus probing (detecting EISA cards available on the bus), allocates I/O resources, allows fancy naming through sysfs, and offers interfaces for driver to register.
- The bus root driver implements the glue between the bus hardware and the generic bus code. It is responsible for discovering the device implementing the bus, and setting it up to be latter probed by the bus code. This can go from something as simple as reserving an I/O region on x86, to the rather more complex, like the hppa EISA code. This is the part to implement in order to have EISA running on an "new" platform.
- The driver offers the bus a list of devices that it manages, and implements the necessary callbacks to probe and release devices whenever told to.

Every function/structure below lives in linux/eisa.h>, which depends heavily on linux/device.h>.

** Bus root driver:

int eisa_root_register (struct eisa_root_device *root);

The eisa_root_register function is used to declare a device as the root of an EISA bus. The eisa_root_device structure holds a reference to this device, as well as some parameters for probing purposes.

```
struct eisa root device {
        struct device
                        *dev:
                                 /* Pointer to bridge device */
        struct resource *res;
                         bus_base_addr;
       unsigned long
                         slots; /* Max slot number */
        int
                         force_probe; /* Probe even when no slot 0 */
        int
       u64
                         dma_mask; /* from bridge device */
                         bus nr; /* Set by eisa root register */
        int
        struct resource eisa_root_res; /* ditto */
                                     第1页
```

```
};
node
              : used for eisa root register internal purpose
               : pointer to the root device
dev
               : root device I/O resource
res
bus base addr: slot 0 address on this bus
              : max slot number to probe
slots
              : Probe even when slot 0 is empty (no EISA mainboard)
force probe
dma mask
              : Default DMA mask. Usually the bridge device dma mask.
bus nr
              : unique bus id, set by eisa root register
** Driver:
int eisa driver register (struct eisa driver *edrv);
void eisa driver unregister (struct eisa driver *edrv);
Clear enough?
struct eisa device id {
        char sig[EISA SIG LEN];
        unsigned long driver data;
};
struct eisa driver {
        const struct eisa device id *id table;
        struct device driver
                                       driver:
};
id table
                 : an array of NULL terminated EISA id strings,
                   followed by an empty string. Each string can
                   optionally be paired with a driver-dependant value
                   (driver data).
                 : a generic driver, such as described in
driver
                   Documentation/driver-model/driver.txt. Only .name.
                   .probe and .remove members are mandatory.
An example is the 3c59x driver:
static struct eisa_device_id vortex_eisa_ids[] = {
          "TCM5920", EISA_3C592_OFFSET },
"TCM5970", EISA_3C597_OFFSET },
};
static struct eisa driver vortex eisa driver = {
        .id table = vortex eisa ids,
                  = {
        .driver
                          = "3c59x",
                 . name
                          = vortex_eisa_probe,
                .probe
                .remove = vortex_eisa_remove
        }
};
** Device:
```

eisa. txt

The sysfs framework calls .probe and .remove functions upon device discovery and removal (note that the .remove function is only called when driver is built as a module).

Both functions are passed a pointer to a 'struct device', which is encapsulated in a 'struct eisa_device' described as follows:

```
struct eisa device {
        struct eisa device id id;
        int
        int
                               state;
        unsigned long
                               base addr;
                               res[EISA MAX RESOURCES];
        struct resource
                               dma mask;
        u64
        struct device
                               dev; /* generic device */
};
id
        : EISA id, as read from device. id. driver data is set from the
          matching driver EISA id.
slot
        : slot number which the device was detected on
        : set of flags indicating the state of the device. Current
state
          flags are EISA_CONFIG_ENABLED and EISA_CONFIG_FORCED.
        : set of four 256 bytes I/O regions allocated to this device
dma mask: DMA mask set from the parent device.
        : generic device (see Documentation/driver-model/device.txt)
You can get the 'struct eisa_device' from 'struct device' using the 'to_eisa_device' macro.
** Misc stuff:
void eisa set drvdata (struct eisa device *edev, void *data);
Stores data into the device's driver data area.
void *eisa get drvdata (struct eisa device *edev):
Gets the pointer previously stored into the device's driver data area.
int eisa get region index (void *addr);
```

Returns the region number (0 \leq x \leq EISA_MAX_RESOURCES) of a given address.

** Kernel parameters :

eisa bus.enable dev :

A comma-separated list of slots to be enabled, even if the firmware set the card as disabled. The driver must be able to properly initialize the device in such conditions.

eisa bus. disable dev :

A comma-separated list of slots to be enabled, even if the firmware set the card as enabled. The driver won't be called to handle this $\Re \ 3 \ \overline{\square}$

eisa.txt

device.

virtual_root.force_probe :

Force the probing code to probe EISA slots even when it cannot find an EISA compliant mainboard (nothing appears on slot 0). Defaults to 0 (don't force), and set to 1 (force probing) when either CONFIG ALPHA JENSEN or CONFIG EISA VLB PRIMING are set.

** Random notes:

Converting an EISA driver to the new API mostly involves *deleting* code (since probing is now in the core EISA code). Unfortunately, most drivers share their probing routine between ISA, MCA and EISA. Special care must be taken when ripping out the EISA code, so other busses won't suffer from these surgical strikes...

You *must not* expect any EISA device to be detected when returning from eisa_driver_register, since the chances are that the bus has not yet been probed. In fact, that's what happens most of the time (the bus root driver usually kicks in rather late in the boot process). Unfortunately, most drivers are doing the probing by themselves, and expect to have explored the whole machine when they exit their probe routine.

For example, switching your favorite EISA SCSI card to the "hotplug" model is "the right thing" (tm).

** Thanks:

I'd like to thank the following people for their help:

- Xavier Benigni for lending me a wonderful Alpha Jensen,
- James Bottomley, Jeff Garzik for getting this stuff into the kernel,
- Andries Brouwer for contributing numerous EISA ids,
- Catrin Jones for coping with far too many machines at home.