```
* Freescale 83xx and 512x PCI bridges
Freescale 83xx and 512x SOCs include the same pci bridge core.
83xx/512x specific notes:
- reg: should contain two address length tuples
    The first is for the internal pci bridge registers
    The second is for the pci config space access registers
Example (MPC8313ERDB)
         pci0: pci@e0008500 {
                  cell-index = \langle 1 \rangle;
                  interrupt-map-mask = \langle 0xf800 \ 0x0 \ 0x0 \ 0x7 \rangle;
                  interrupt-map = <
                                     /* IDSEL 0x0E -mini PCI */
                                      0x7000 0x0 0x0 0x1 &ipic 18 0x8
                                      0x7000 0x0 0x0 0x2 &ipic 18 0x8
                                      0x7000 0x0 0x0 0x3 &ipic 18 0x8
                                      0x7000 0x0 0x0 0x4 &ipic 18 0x8
                                     /* IDSEL 0x0F - PCI slot */
                                      0x7800 0x0 0x0 0x1 &ipic 17 0x8
                                      0x7800 0x0 0x0 0x2 &ipic 18 0x8
                                      0x7800 0x0 0x0 0x3 &ipic 17 0x8
                                      0x7800 0x0 0x0 0x4 &ipic 18 0x8>;
                  interrupt-parent = <&ipic>;
                  interrupts = \langle 66 \ 0x8 \rangle;
                  bus-range = \langle 0x0 \ 0x0 \rangle;
                  ranges = \langle 0x02000000 \ 0x0 \ 0x90000000 \ 0x90000000 \ 0x0 \ 0x10000000
                              0x42000000 \ 0x0 \ 0x80000000 \ 0x80000000 \ 0x0 \ 0x10000000
                              0x01000000 \ 0x0 \ 0x000000000 \ 0xe2000000 \ 0x0 \ 0x001000000;
                  clock-frequency = \langle 666666666 \rangle;
                  #interrupt-cells = <1>;
                  \#size-cells = \langle 2 \rangle;
                  \#address-cells = \langle 3 \rangle:
                  reg = \langle 0xe0008500 \ 0x100 \rangle
                                                       /* internal registers */
                          0xe0008300 \ 0x8>;
                                                       /* config space access registers
*/
                  compatible = "fs1, mpc8349-pci";
                  device_type = "pci";
         };
```

83xx-512x-pci.txt