sysfs-driver-hid-roccat-kone..txt

What: /sys/bus/usb/devices/\langle busnum\rangle -\langle devnum\rangle :\langle config num\rangle .\langle interface

num>/actual dpi

Date: March 2010

Contact: Stefan Achatz <erazor de@users.sourceforge.net>

Description: It is possible to switch the dpi setting of the mouse with the

press of a button.

When read, this file returns the raw number of the actual dpi setting reported by the mouse. This number has to be further processed to receive the real dpi value.

This file is readonly.

What: /sys/bus/usb/devices/<busnum>-<devnum>:<config num>. <interface

num>/actual_profile

Date: March 2010

Contact: Stefan Achatz <erazor de@users.sourceforge.net>

Description: When read, this file returns the number of the actual profile.

This file is readonly.

What: /sys/bus/usb/devices/\langle busnum\rangle -\langle devnum\rangle :\langle config num\rangle . \langle interface

num>/firmware_version

Date: March 2010

Contact: Stefan Achatz <erazor de@users.sourceforge.net>

Description: When read, this file returns the raw integer version number of

the

firmware reported by the mouse. Using the integer value eases further usage in other programs. To receive the real version number the decimal point has to be shifted 2 positions to the

left. E.g. a returned value of 138 means 1.38

This file is readonly.

What: /sys/bus/usb/devices/\busnum\-\devnum\:\config num\.\dinterface

num>/kone_driver_version
Date: March 2010

Contact: Stefan Achatz <erazor_de@users.sourceforge.net> Description: When read, this file returns the driver version.

The format of the string is "v<major>. <minor>. <patchlevel>".

This attribute is used by the userland tools to find the sysfspaths of installed kone-mice and determine the capabilites of
the driver. Versions of this driver for old kernels replace
usbhid instead of generic-usb. The way to scan for this file
has been chosen to provide a consistent way for all supported

kernel versions.

This file is readonly.

num>/profile[1-5]

Date: March 2010

sysfs-driver-hid-roccat-kone..txt

Contact:

Stefan Achatz <erazor de@users.sourceforge.net>

Description: The mouse can store 5 profiles which can be switched by the press of a button. A profile holds informations like button mappings, sensitivity, the colors of the 5 leds and light

effects.

When read, these files return the respective profile. The

returned data is 975 bytes in size.

When written, this file lets one write the respective profile data back to the mouse. The data has to be 975 bytes long. The mouse will reject invalid data, whereas the profile number stored in the profile doesn't need to fit the number of the

store.

What:

/sys/bus/usb/devices/\langle busnum\rangle -\langle devnum\rangle :\langle config num\rangle .\langle interface

num>/settings

Date:

March 2010 Stefan Achatz <erazor de@users.sourceforge.net>

Contact: Description:

When read, this file returns the settings stored in the mouse. The size of the data is 36 bytes and holds information like the

startup profile, tcu state and calibration_data.

When written, this file lets write settings back to the mouse. The data has to be 36 bytes long. The mouse will reject invalid

data.

/sys/bus/usb/devices/\langle busnum\rangle -\langle devnum\rangle :\langle config num\rangle .\langle interface

num>/startup_profile

Date: March 2010

Stefan Achatz <erazor de@users.sourceforge.net> Contact:

Description: The integer value of this attribute ranges from 1 to 5.

When read, this attribute returns the number of the profile

that's active when the mouse is powered on.

When written, this file sets the number of the startup profile

and the mouse activates this profile immediately.

What:

/sys/bus/usb/devices/\devnum\-\devnum\:\config num\.\dinterface

num>/tcu

Date:

March 2010

Contact:

Stefan Achatz <erazor de@users.sourceforge.net>

Description: The mouse has a "Tracking Control Unit" which lets the user

> calibrate the laser power to fit the mousepad surface. When read, this file returns the current state of the TCU,

where 0 means off and 1 means on.

Writing 0 in this file will switch the TCU off.

Writing 1 in this file will start the calibration which takes

around 6 seconds to complete and activates the TCU.

What:

/sys/bus/usb/devices/\langle busnum\rangle -\langle devnum\rangle :\langle config num\rangle .\langle interface

num>/weight

Date:

March 2010

Contact:

Stefan Achatz <erazor de@users.sourceforge.net>

Description:

The mouse can be equipped with one of four supplied weights ranging from 5 to 20 grams which are recognized by the mouse and its value can be read out. When read, this file returns the raw value returned by the mouse which eases further processing

in other software.

The values map to the weights as follows:

第 2 页

sysfs-driver-hid-roccat-kone..txt

VALUE WEIGHT 0 none 1 5g 2 10g 3 15g 4 20g

This file is readonly.