```
ndfc. txt
```

AMCC NDFC (NanD Flash Controller) Required properties: - compatible : "ibm, ndfc". - reg: should specify chip select and size used for the chip (0x2000). Optional properties: - ccr : NDFC config and control register value (default 0). - bank-settings: NDFC bank configuration register value (default 0). Notes: - partition(s) - follows the OF MTD standard for partitions Example: ndfc@1, 0 { compatible = "ibm, ndfc"; $reg = \langle 0x00000001 \ 0x00000000 \ 0x00002000 \rangle;$ $ccr = \langle 0x00001000 \rangle;$ bank-settings = $\langle 0x80002222 \rangle$; $\#address-cells = \langle 1 \rangle;$ #size-cells = $\langle 1 \rangle$; nand { #address-cells = <1>; $\#size-cells = \langle 1 \rangle;$ partition@0 { label = "kernel"; $reg = \langle 0x00000000 \ 0x002000000 \rangle;$ }; partition@200000 { label = "root"; $reg = \langle 0x00200000 \ 0x03E000000 \rangle;$ }; }; };